



Operational and Scientific Monitoring Plan

Addendum 2: Thylacine Installation and Commissioning EP

Review record (record the last 3 revisions here or the revisions required to achieve current approval version)

Revision	Date	Reason for issue	Reviewer/s	Consolidator	Approver
A	02/09/22	Beach Review	PW	Aventus	PW
0	02/09/22	Submission to NOPSEMA	PW	Aventus	PW
1	21/12/22	Submission to NOPSEMA	PW	Aventus	PW

Review due	Review frequency
Annually from date of acceptance	1 year/s

For internal use and distribution only. Subject to employee confidentiality obligations. Once printed, this is an uncontrolled document unless issued and stamped Controlled Copy or issued under a transmittal.

THE THREE WHATS

What can go wrong?

What could cause it to go wrong?

What can I do to prevent it?

Table of contents

1	Introduction	3
1.1	Purpose	3
1.2	Environment that may be affected	3
1.3	Spill Scenarios	3
2	Environmental Values and Sensitivities	5
3	Priority Planning for Scientific Monitoring	12
4	Implementation Plan	14
4.1	Activation	14
4.2	Immediate response	14
4.3	Roles and responsibilities	14
4.4	Capability, training and competency	15
4.5	Sampling and Analysis Plans for Scientific Monitoring	15
4.6	Study Logistics	15
4.7	Survey Schedule	15
4.8	Permits	15

Table of figures

Figure 1-1:	Environment that may be affected	4
-------------	----------------------------------	---

List of tables

Table 2-1:	Environmental values and sensitivities of key areas within the EMBA that may be exposed to oil	6
Table 3-1:	Priority planning areas and scientific studies for the Thylacine Subsea Installation and Commissioning EP	12
Table 4-1:	Key Beach personnel for OSMP implementation	14
Table 4-2:	Key Monitoring Provider personnel for OSMP implementation	14
Table 4-3:	OSMP Capability Needs Assessment	16
Table 4-4:	Permits that may be required for scientific monitoring	21

List of appendices

Appendix A	Scientific Monitoring Priority Planning Area Summaries	23
A. 1.	Apollo Marine Park	23
A. 2.	Twelve Apostles Marine National Park	24
A. 3.	Prinetown Wetlands	25
Appendix B	Standard Operating Procedures for Water and Sediment Sampling	26
B. 1.	Water Sampling – Surface Waters	26
B. 2.	Water Sampling – Subsurface Waters	27
B. 3.	Sediment Sampling	28
B. 4.	Cleaning and Care	28
B. 5.	Chain of Custody	28
B. 6.	Sample Transport and Storage	29

1 Introduction

1.1 Purpose

This document is an addendum to the Offshore Victoria Operational and Scientific Monitoring Plan (OSMP) (CDN/ID S4100AH717908) to incorporate the Thylacine Subsea Installation and Commissioning EP (CDN/ID: S4121AF728393) activity. It provides a description of the:

- Worst-case spill scenarios;
- Matters of national environmental significance (MNES) within the environment that may be affected (EMBA) and predicted oil exposure from stochastic spill modelling;
- Environmental values and sensitivities of key areas within the EMBA and the operational and scientific monitoring studies that may be relevant to these areas;
- Priority planning areas for scientific studies; and
- Environmental monitoring implementation plan.

1.2 Environment that may be affected

The EMBA has been defined as an area where a change to ambient environmental conditions may potentially occur as a result of planned or unplanned activities. It is noted that a change does not always imply that an adverse impact will occur; for example, a change may be required over a particular exposure value or over a consistent period of time for a subsequent impact to occur. The EMBA defined for the Thylacine Subsea Installation and Commissioning EP is defined in Section 5.1 of the EP and shown in Figure 1-1.

1.3 Spill Scenarios

The credible worst-case spill scenario modelled for the EP was a surface release over six hours of 300 m³ of marine diesel oil (MDO). The risk assessment for this scenario is included at Section 7.16 of the EP. Risks associated with response activities are assessed in Section 7.17. The oil spill trajectory modelling is included as Appendix D of the EP.




Figure 1-1: Environment that may be affected

2 Environmental Values and Sensitivities

Chapter 5 of the EP describes the environmental values and sensitivities within the EMBA. The information presented in this section is based on spatial extents of stochastic spill modelling (Section 1.3) and/or the EMBA and the MNES and other environmental features identified within the EP. The information is presented here as context for spill monitoring awareness and planning. It does not restrict the implementation of any monitoring of MNES (or other) features that may be affected by an actual spill event that are beyond the area of predicted oil exposure; i.e. once the relevant initiation criteria are met for an operational and/or scientific study, these can be implemented irrespective of previous modelling outcomes.

Table 2-1 provides a summary of environmental values and sensitivities of identified key areas within the EMBA. Key areas were determined as:

- Australian Marine Parks within the EMBA;
- Wetlands of International Importance (Ramsar wetlands) within the EMBA;
- Threatened ecological communities within the EMBA;
- Threatened or migratory species with a spatially defined biologically important area (BIA) within the EMBA;
- Key Ecological Features (KEFs) within the EMBA; and
- Other protected areas within the EMBA, including State protected marine and terrestrial areas, nationally important wetlands, and heritage features.

The description of values and sensitivities is summarised from Chapter 5 (Description of the Environment) of the EP.

Addendum 2: Thylacine Installation and Commissioning EP

Table 2-1: Environmental values and sensitivities of key areas within the EMBA that may be exposed to oil

Key Area Location / Feature	Summary of Environmental Values and Sensitivities	Relevant Management Plan / Conservation Advice / Recovery Plan	Relevant Operational and Scientific Monitoring Studies
Australian Marine Parks			
Apollo Marine Park	<ul style="list-style-type: none"> Ecosystems, habitats and communities associated with the Western Bass Strait Shelf Transition and the Bass Strait Shelf Province and associated with the seafloor features: deep/hole/valley and shelf Important migration area for blue, fin, sei and humpback whales Important foraging area for black-browed and shy albatross, Australasian gannet, short-tailed shearwater and crested tern Cultural and heritage site – wreck of the MV City of Rayville 	South-east Commonwealth Marine Reserves Network Management Plan 2013-2023	O2: Water quality O3: Sediment quality O4: Marine fauna surveillance S1: Water quality impact assessment S2: Sediment quality impact assessment S3: Subtidal habitats impact assessment S5: Marine fauna impact assessment S7: Heritage and socioeconomic impact assessment
Zeehan Marine Park	<ul style="list-style-type: none"> Examples of ecosystems, habitats and communities associated with the Tasmania Province, the West Tasmania Transition and the Western Bass Strait Shelf Transition and associated with the seafloor features: abyssal plain/deep ocean floor, canyon, deep/hole/valley, knoll/abyssal hill, shelf and slope Important migration area for blue and humpback whales Important foraging habitat for black-browed, wandering and shy albatrosses, and great-winged and cape petrels 		O2: Water quality O3: Sediment quality O4: Marine fauna surveillance S1: Water quality impact assessment S2: Sediment quality impact assessment S3: Subtidal habitats impact assessment S5: Marine fauna impact assessment
State Marine Protected Areas			
Victoria (Marine National Parks)			
Twelve Apostles Marine Park	<ul style="list-style-type: none"> The area is representative of the Otway Bioregion and is characterised by a submarine network of towering canyons, caves, arches and walls with a large variety of seaweed and sponge gardens plus resident schools of reef fish. The park contains areas of calcarenite reef supporting the highest diversity of intertidal and sub-tidal invertebrates found on that rock type in Victoria 	Management Plan for Twelve Apostles Marine National Park and The Arches Marine Sanctuary	

Addendum 2: Thylacine Installation and Commissioning EP

Key Area Location / Feature	Summary of Environmental Values and Sensitivities	Relevant Management Plan / Conservation Advice / Recovery Plan	Relevant Operational and Scientific Monitoring Studies
	<ul style="list-style-type: none"> The park includes large sandy sub-tidal areas consisting of predominantly fine sand with some medium to coarse sand and shell fragment. Benthic sampling undertaken within the park in soft sediment habitats at 10 m, 20 m and 40 m water depths identified 31, 29 and 32 species respectively based upon a sample area of 0.1 m². These species were predominantly polychaetes, crustaceans and nematodes with the mean number of individuals decreasing with water depth. No visible macroalgae species were present within these soft sediment areas. These sandy expanses support high abundances of smaller animals such as worms, small molluscs and crustaceans; larger animals are less common. 		
State Terrestrial Protected Areas			
Victoria (National Parks)			
Great Otway National Park	<ul style="list-style-type: none"> Mainland or island-based protected areas with a coastal interface that may be used as habitat for marine fauna (birds, pinnipeds etc) 	Great Otway National Park and Otway Forest Park Management Plan	O3: Sediment quality O4: Marine fauna surveillance
Port Campbell National Park	<ul style="list-style-type: none"> Where access is allowed, recreational activities may be present 	Port Campbell National Park Management Plan	S2: Sediment quality impact assessment S4: Intertidal and coastal habitats impact assessment S5: Marine fauna impact assessment S7: Heritage and socioeconomic impact assessment
Tasmania			
Cape Wickham Conservation Area		N/A	
Christmas Island Nature Reserve		N/A	
New Year Island Game Reserve		N/A	
Seal Rocks State Reserve		N/A	

Addendum 2: Thylacine Installation and Commissioning EP

Key Area Location / Feature	Summary of Environmental Values and Sensitivities	Relevant Management Plan / Conservation Advice / Recovery Plan	Relevant Operational and Scientific Monitoring Studies
Disappointment Bay State Reserve		N/A	
Cataraqui Point Conservation Area		N/A	
Porky Beach Conservation Area		N/A	
Nationally Important Wetlands			
Princetown Wetlands	<ul style="list-style-type: none"> These wetlands consist of swamps of varying salinity on the floodplains of the Gellibrand River and its tributary, the Serpentine (Latrobe) Creek. Wetlands types present are a deep freshwater marsh, semi- permanent saline marshes and a shallow freshwater marsh The Princetown Wetlands have extensive beds of Common Reed <i>Phragmites australis</i> and meadows dominated by Beaded Glasswort which can support large numbers of water birds. A series of relict spits adjacent to the Gellibrand Estuary and a number of levee banks at various sites have State significance for their geomorphology. 	N/A	<p>O2: Water quality O3: Sediment quality O4: Marine fauna surveillance S1: Water quality impact assessment S2: Sediment quality impact assessment S4: Intertidal and coastal habitats impact assessment S5: Marine fauna impact assessment S7: Heritage and socioeconomic impact assessment</p>
Threatened Ecological Communities			
Assemblages of species associated with open-coast salt-wedge estuaries of western and central Victoria ecological community	<ul style="list-style-type: none"> This ecological community is the assemblage of native plants, animals and micro-organisms associated with the dynamic salt-wedge estuary systems that occur within the temperate climate, microtidal regime (<2 m), high wave energy coastline of western and central Victoria. The ecological community currently encompasses 25 estuaries in the region defined by the border between South Australia and Victoria and the most southerly point of Wilsons Promontory. 	Approved Conservation for the Assemblages of species associated with open-coast salt-wedge estuaries of western and central Victoria ecological community	<p>O2: Water quality O3: Sediment quality S1: Water quality impact assessment S2: Sediment quality impact assessment S4: Intertidal and coastal habitats impact assessment</p>
Giant Kelp Marine Forests of South East Australia	<ul style="list-style-type: none"> Giant kelp (<i>Macrocystis pyrifera</i>) is a large brown alga that grows on rocky reefs in cold temperate waters off south east Australia. The kelp grows up from the sea floor 8 m below the sea surface and deeper, vertically toward the water surface. It is the foundation species of this 	Approved Conservation Advice for Giant Kelp Marine Forests of South East Australia	<p>O2: Water quality O3: Sediment quality S1: Water quality impact assessment</p>

Addendum 2: Thylacine Installation and Commissioning EP

Key Area Location / Feature	Summary of Environmental Values and Sensitivities	Relevant Management Plan / Conservation Advice / Recovery Plan	Relevant Operational and Scientific Monitoring Studies
	<p>TEC in shallow coastal marine ecological communities. The kelp species itself is not protected, rather, it is communities of closed or semi-closed giant kelp canopy at or below the sea surface that are protected</p> <ul style="list-style-type: none"> The largest extent of the ecological community is in Tasmanian coastal waters; some patches may also be found in Victoria and South Australia. Surveys along the Otway Shelf from Warrnambool to Portland did not locate giant kelp at any site. Surveys of The Arches Marine Sanctuary and Twelve Apostles Marine National Park have not located giant kelp. The species has been recorded on King Island. 		<p>S2: Sediment quality impact assessment S3: Subtidal habitats impact assessment</p>
Subtropical and Temperate Coastal Saltmarsh	<ul style="list-style-type: none"> The coastal saltmarsh community consists mainly of salt-tolerant vegetation including grasses, herbs, sedges, rushes and shrubs. Succulent herbs, shrubs and grasses generally dominate, and vegetation is generally less than 0.5 m in height. The saltmarsh community is inhabited by a wide range of infaunal and epifaunal invertebrates and low and high tide visitors such as fish, birds and prawns It is often important nursery habitat for fish and prawn species. Insects are also abundance and an important food source for other fauna. The dominant marine residents are benthic invertebrates, including molluscs and crabs 	Conservation Advice for Subtropical and Coastal Saltmarsh	<p>O2: Water quality O3: Sediment quality S1: Water quality impact assessment S2: Sediment quality impact assessment S4: Intertidal and coastal habitats impact assessment</p>
Threatened or Migratory Fauna with BIAs			
White Shark	<ul style="list-style-type: none"> Vulnerable, migratory Foraging and distribution BIAs 	Recovery Plan for the White Shark (<i>Carcharodon carcharias</i>)	<p>O4: Marine fauna surveillance S5: Marine fauna impact assessment</p>
Southern Right Whale	<ul style="list-style-type: none"> Endangered, migratory Aggregation, distribution, migration and resting, and connecting habitat BIAs Presence may occur from May to November 	Conservation Management Plan for the Southern Right Whale, 2011-2021	<p>O4: Marine fauna surveillance S5: Marine fauna impact assessment</p>

Addendum 2: Thylacine Installation and Commissioning EP

Key Area Location / Feature	Summary of Environmental Values and Sensitivities	Relevant Management Plan / Conservation Advice / Recovery Plan	Relevant Operational and Scientific Monitoring Studies
Pygmy Blue Whale	<ul style="list-style-type: none"> Endangered, migratory Foraging, foraging (annual high use area) and distribution BIAs Typically forage in the Otway region between January and April 	Conservation Management Plan for the Blue Whale, 2015-2025	<p>O4: Marine fauna surveillance</p> <p>S5: Marine fauna impact assessment</p>
Antipodean Albatross	<ul style="list-style-type: none"> Vulnerable, migratory Foraging BIA 	National recovery plan for threatened albatrosses and giant petrels 2011-2016	<p>O4: Marine fauna surveillance</p> <p>S5: Marine fauna impact assessment</p>
Black-browed Albatross	<ul style="list-style-type: none"> Vulnerable, migratory Foraging BIA 		
Buller's Albatross	<ul style="list-style-type: none"> Vulnerable, migratory Foraging BIA 		
Campbell Albatross	<ul style="list-style-type: none"> Vulnerable, migratory Foraging BIA 		
Indian Yellow-nosed Albatross	<ul style="list-style-type: none"> Vulnerable, migratory Foraging BIA 		
Shy Albatross	<ul style="list-style-type: none"> Vulnerable, migratory Foraging and breeding BIAs 		
Wandering Albatross	<ul style="list-style-type: none"> Vulnerable, migratory Foraging BIA 		
Short-tailed Shearwater	<ul style="list-style-type: none"> Migratory Foraging and breeding BIAs 	Wildlife Conservation Plan for Seabirds (Commonwealth of Australia 2020)	<p>O4: Marine fauna surveillance</p> <p>S5: Marine fauna impact assessment</p>
Wedge-tailed Shearwater	<ul style="list-style-type: none"> Migratory Foraging BIA 		
Australasian gannet	<ul style="list-style-type: none"> Foraging and aggregation BIAs 		
Black-faced cormorant	<ul style="list-style-type: none"> Foraging and breeding BIAs 		

Addendum 2: Thylacine Installation and Commissioning EP

Key Area Location / Feature	Summary of Environmental Values and Sensitivities	Relevant Management Plan / Conservation Advice / Recovery Plan	Relevant Operational and Scientific Monitoring Studies
Common diving-petrel	<ul style="list-style-type: none"> Foraging and breeding BIAs 		
Little Penguin	<ul style="list-style-type: none"> Foraging and breeding BIAs 		
Key Ecological Features			
West Tasmanian Canyons	<ul style="list-style-type: none"> An area of high productivity and aggregations of marine life. These canyons can influence currents, act as sinks for rich organic sediments and debris, and can trap waters or create upwellings that result in productivity and biodiversity hotspots. Sponges are concentrated near the canyon heads, with the greatest diversity between 200-350 m depth. Sponges are associated with abundance of fishes and the canyons support a diversity of sponges comparable to that of seamounts. 	N/A	<ul style="list-style-type: none"> O2: Water quality O3: Sediment quality S1: Water quality impact assessment S2: Sediment quality impact assessment S3: Subtidal habitats impact assessment
Shelf Rocky Reefs and Hard Substrates	<ul style="list-style-type: none"> An area of high productivity and aggregations of marine life. Rocky reefs and hard grounds provide attachment sites for macroalgae and sessile invertebrates, increasing the structural diversity of shelf ecosystems. The reefs provide habitat and shelter for fish and are important for aggregations of biodiversity and enhanced productivity. 	N/A	<ul style="list-style-type: none"> O2: Water quality O3: Sediment quality S1: Water quality impact assessment S2: Sediment quality impact assessment S3: Subtidal habitats impact assessment
Bass Cascade	<ul style="list-style-type: none"> An area of high productivity and aggregations of marine life. The mixing of water flows at the Bass Cascades can cause nutrient rich waters to rise, which in turn leads to increased primary productivity in those areas. The cascading water also concentrates nutrients and some fish and whales are known to aggregate along its leading edge. 	N/A	<ul style="list-style-type: none"> O2: Water quality O4: Marine fauna surveillance S1: Water quality impact assessment S5: Marine fauna impact assessment

3 Priority Planning for Scientific Monitoring

Priority planning for scientific monitoring has been developed based on two elements: (i) sensitive areas that may be exposed within a short-period of time, and (ii) study scopes that have a short lead time on preparing an initial Sampling and Analysis Plan (SAP) for implementation.

Priority planning areas for potential scientific monitoring have been identified where the following criteria are met:

- Predicted time to exposure is ≤ 48 hours **or** distance from the Thylacine Installation and Commissioning EP activity area is ≤ 100 km, **and**;
- Any of the following sensitive environmental receptors are present:
 - Australian Marine Parks
 - State marine protected areas
 - National or internationally important wetlands
 - Mangrove or saltmarsh habitat
 - Known breeding/calving/nesting aggregation areas for protected (threatened or migratory) fauna
 - Known breeding/haul-out areas for pinnipeds
 - Threatened ecological communities; **and**
- Time given for preparation of an initial SAP for a particular scientific monitoring study is ≤ 48 hours.

Note, the time requirement is based upon the shortest time allowed (i.e., 48 hours) for the Monitoring Provider to prepare an initial SAP for a scientific monitoring study (as defined in the Offshore Victoria OSMP [CDN/ID S4100AH717908]).

The selection of sensitive environmental receptors is consistent with the receptors used in determining the onshore priority response planning areas within the OPEP, with the addition of marine protected areas (both Commonwealth and State).

The priority planning areas and relevant scientific monitoring scopes identified for spill scenarios that are relevant to the EP are detailed in Table 3-1. A series of checklists have been developed for these priority planning areas to assist in implementing scientific monitoring studies in these areas (Appendix A).

Table 3-1: Priority planning areas and scientific studies for the Thylacine Subsea Installation and Commissioning EP

Sensitive Environmental Receptor	Priority Planning Area	Priority Scientific Studies
Australian Marine Parks	Apollo Marine Park	S1: Water quality impact assessment
Victorian state marine protected areas	Twelve Apostles Marine National Park	S2: Sediment quality impact assessment
Tasmanian state marine protected areas	New Year Island Game Reserve	S1: Water quality impact assessment
	Christmas Island Nature Reserve	S2: Sediment quality impact assessment

Sensitive Environmental Receptor	Priority Planning Area	Priority Scientific Studies
Nationally important wetlands	Prinetown Wetlands	S1: Water quality impact assessment S2: Sediment quality impact assessment
Sheltered tidal flats	None	
Mangrove habitat	None	
Saltmarsh habitat	Prinetown Wetlands	S1: Water quality impact assessment S2: Sediment quality impact assessment
Known breeding/calving/nesting aggregation areas for protected fauna	New Year Island (King Island), Christmas Island (King Island) (breeding/foraging BIA for little penguin)	S1: Water quality impact assessment S2: Sediment quality impact assessment
Threatened ecological communities (Giant Kelp)	Twelve Apostles Marine National Park	S1: Water quality impact assessment S2: Sediment quality impact assessment
Threatened ecological communities (Coastal Saltmarsh and/or Salt-wedge Assemblages)	Prinetown Wetlands	S1: Water quality impact assessment S2: Sediment quality impact assessment
Threatened ecological communities (Subtropical and temperate coastal saltmarsh)	Twelve Apostles Marine National Park	S1: Water quality impact assessment S2: Sediment quality impact assessment
	King Island	S1: Water quality impact assessment S2: Sediment quality impact assessment

4 Implementation Plan

4.1 Activation

In the unlikely event of a Level 2 or Level 3 offshore spill event, operational and scientific monitoring studies will be initiated once the relevant criteria have been met (as defined in the Offshore Victoria OSMP [CDN/ID S4100AH717908]). The EMT Environment Leader (or delegate) will contact the Monitoring Provider Program Manager who will initiate their response.

4.2 Immediate response

Once notified, the Monitoring Provider Program Manager will confirm the availability of Study Leads, and specific sampling and analysis plans (SAPs) will be prepared based on the requirements of the individual spill event. Based on initiated studies and SAPs, personnel, equipment and mobilisation will commence.

4.3 Roles and responsibilities

The key roles and responsibilities for implementation of the OSMP are defined in Table 3-1 of the Offshore Victoria OSMP (CDN/ID S4100AH717908).

Key personnel within Beach with OSMP responsibilities during the activity are listed in Table 4-1.

The Monitoring Provider and associated personnel will be identified and activated on a case-by-case basis. RPS have confirmed they have a pool of suitably trained and competent personnel to utilise in the event of a Level 2 or Level 3 hydrocarbon spill event. An annual review is undertaken of the Beach operational and scientific monitoring capabilities to ensure that the Offshore Victoria OSMP can be effectively implemented. The key personnel for the monitoring scopes are listed in Table 4-2.

Table 4-1: Key Beach personnel for OSMP implementation

Role	Name	Contact Details
Emergency Management Team (EMT) Leader	As per the on-call EMT Roster (refer to OPEP for details)	
EMT Environment Leader	As per the on-call EMT Roster (refer to OPEP for details)	

Table 4-2: Key Monitoring Provider personnel for OSMP implementation

Role	Name	Contact Details
Program Manager	Jeremy Fitzpatrick	08 9211 1111 jeremy.fitzpatrick@rpsgroup.com.au
Study Lead/s	Jeremy Fitzpatrick	08 9211 1111 jeremy.fitzpatrick@rpsgroup.com.au
	Kim Taylor	
	Dr Mike Mackie	
	Dr Matthew Fraser	
	Peter Crockett	
	Tamara Al-Hashimi	

4.4 Capability, training and competency

Table 4-3 details the capability assessment for the implementation of the OSMP studies. It identifies the minimum number of personnel to manage and implement the OSMP studies and platforms (vessel, aircraft or vehicles) required to perform the studies. The studies have been grouped where appropriate to ensure effective use of resources.

The number of resources identified is based on:

- Deterministic scenarios from the modelling report (see Appendix D of the EP).
- higher concentrations of hydrocarbon are spatially limited to the vicinity of the release location (i.e. at the moderate exposure threshold of 10 g/m² the predicted surface exposure is up to a maximum of 24.5 km); however it is noted that lower concentrations that require monitoring do extend beyond these distances.

RPS have confirmed they have a pool of suitably trained and competent personnel to fulfil the requirements of the OSMP.

4.5 Sampling and Analysis Plans for Scientific Monitoring

Study S1 (water quality) and S2 (sediment quality) have implementation times of 72 hours once the study has been activated (refer to Offshore Victoria OSMP [CDN/ID S4100AH717908]). Due to the short implementation time, draft standard operating procedures (SOP) have been prepared and are attached here as Appendix B.

As the implementation times for the other scientific studies are longer (4–5 days), specific SAPs including SOP will be developed post-event by the Monitoring Provider. These will be based on the details provided in the Offshore Victoria OSMP (CDN/ID S4100AH717908) and made fit for purpose to the nature and scale of the actual spill event.

4.6 Study Logistics

All field logistics in regard to survey timing, scheduling and scope are subject to safe operating conditions in accordance with Beach (and/or their Monitoring Providers) health, environment and safety policies. This includes the requirements for any additional qualifications and training for field personnel (e.g., medicals, BOSIET, HUET, ADAS Level 2, Coxswains etc.)

4.7 Survey Schedule

Survey scheduling (in terms of locations and sampling order) will be at the discretion of the Study Lead taking into account existing and predicted oil distributions, proximity to environmental sensitivities and forecasted weather/sea state conditions.

4.8 Permits

The EMBA for the worst-case spill scenario extends through Commonwealth, Victorian and Tasmanian waters. The permits generally required by the governments are listed in Table 4-4. Permit applications require details on the samples to be collected (including timing, species, numbers, methods to be used etc.), and can take up to approximately six weeks for approval. However, in the event of an oil spill, this process is likely to expedited and/or given exemptions.

The Monitoring Provider will confirm the need for any permits during the development of an initial SAP once a spill event has occurred.

Operational and Scientific Monitoring Plan

Addendum 2: Thylacine Installation and Commissioning EP

CDN/ID S4111AF725810.1

Table 4-3: OSMP Capability Needs Assessment

Scope Description	Operational / Scientific Study	Study Lead	Field / Office Personnel	Platform
Program Manager	All	One Program Manager: <ul style="list-style-type: none"> Bachelor degree in environmental science/engineering (or equivalent) >20 years' experience in environmental practice Familiar OSMP and OPEP, as relevant 	N/A	N/A
Oil, water and sediment sampling	O1: Oil characterisation and behaviour O2: Water quality O3: Sediment quality (offshore and intertidal) S1: Water quality impact assessment S2: Sediment quality impact assessment	One Study Lead: <ul style="list-style-type: none"> Bachelor degree in environmental science/engineering (or equivalent) >10 years' experience in environmental practice Familiar OSMP and OPEP, as relevant 	Two vessel personnel: <ul style="list-style-type: none"> Bachelor degree in environmental science/engineering or equivalent >5 years' experience in environmental practice Experienced in the relevant sampling and/or recording techniques Familiar with oil, water and sediment sampling and recording techniques including insitu profiling). One of the vessel personnel: <ul style="list-style-type: none"> Familiar with oil visual observations. Two office personnel: <ul style="list-style-type: none"> Bachelor degree in environmental science/engineering or equivalent > 5 years' experience in environmental practice Experienced in water and sediment quality data analysis 	Two vessels
Dispersant efficacy	O5: Dispersant efficacy <i>Note: aerial surveillance requirements are detailed within the Monitor and Evaluate response within the OPEP</i>	One Study Lead: <ul style="list-style-type: none"> Bachelor degree in environmental science/engineering (or equivalent) >10 years' experience in environmental practice Familiar OSMP and OPEP, as relevant 	Two vessel personnel: <ul style="list-style-type: none"> Familiar with vessel-based oil spill monitoring Familiar with relevant sampling techniques (e.g. sub-surface video surveillance, use of fluorometer, water sample collection) One vessel personnel: <ul style="list-style-type: none"> Experience with ROV/UVA scopes Experience with air quality monitoring 	One vessel

Addendum 2: Thylacine Installation and Commissioning EP

Scope Description	Operational / Scientific Study	Study Lead	Field / Office Personnel	Platform
Fish tainting, impact and recovery	O6: Fish tainting S6: Fisheries impact assessment	One Study Lead: <ul style="list-style-type: none"> Bachelor degree in environmental science/engineering (or equivalent) >10 years' experience in environmental practice Familiar OSMP and OPEP, as relevant 	One vessel personnel: <ul style="list-style-type: none"> Bachelor degree in environmental science/engineering or equivalent >5 years' experience in environmental practice Experienced in the relevant sampling and/or recording techniques (biological tissue sampling, sensory analysis) One vessel personnel: <ul style="list-style-type: none"> Familiar with oil and water sampling and recording techniques (hydrocarbon sensory assessment, field biological tissue sampling) Trained and/or experienced olfactory analysts One office personnel: <ul style="list-style-type: none"> Bachelor degree in environmental science/engineering or equivalent > 5 years' experience in environmental practice Experience in analysis and interpretation of biota data 	One vessel
Intertidal and subtidal habitat impact and recovery	S3: Subtidal habitats impact assessment S4: Intertidal and coastal habitats impact assessment	One Study Lead: <ul style="list-style-type: none"> Bachelor degree in environmental science/engineering (or equivalent) >10 years' experience in environmental practice Familiar OSMP and OPEP, as relevant 	Four vessel personnel: <ul style="list-style-type: none"> Bachelor degree in environmental science/engineering or equivalent >5 years' experience in environmental practice Commercial dive qualifications Experienced in the relevant sampling and/or recording techniques One vessel personnel: <ul style="list-style-type: none"> Experienced in commercial ROV operations Two mainland personnel: <ul style="list-style-type: none"> Bachelor degree in environmental science/engineering or equivalent >5 years' experience in environmental practice Experienced in the relevant sampling and/or recording techniques Two office personnel: <ul style="list-style-type: none"> Bachelor degree in environmental science/engineering or equivalent 	Two vessels One vehicle

Addendum 2: Thylacine Installation and Commissioning EP

Scope Description	Operational / Scientific Study	Study Lead	Field / Office Personnel	Platform
			<ul style="list-style-type: none"> >5 years' experience in environmental practice Experienced in identification, analysis and interpretation of benthic habitat data and sediment quality data analysis 	
Coastal habitat impact and recovery	<p>O3: Sediment quality (shoreline)</p> <p>S2: Sediment quality (shoreline) impact assessment</p> <p>S4: Intertidal and coastal habitats impact assessment</p>	<p>One Study Lead:</p> <ul style="list-style-type: none"> Bachelor degree in environmental science/engineering (or equivalent) >10 years' experience in environmental practice <p>Familiar OSMP and OPEP, as relevant</p>	<p>Four mainland personnel:</p> <ul style="list-style-type: none"> Bachelor degree in environmental science/engineering or equivalent >5 years' experience in environmental practice Experienced in the relevant sampling and/or recording techniques <p>Two of the mainland personnel:</p> <ul style="list-style-type: none"> Familiar with sediment sampling and recording techniques <p>Two office personnel:</p> <ul style="list-style-type: none"> Bachelor degree in environmental science/engineering or equivalent >5 years' experience in environmental practice Experienced in identification, analysis and interpretation of benthic habitat data and sediment quality data analysis 	Two vehicles
Marine fauna surveillance, impact and recovery	<p>O4: Marine fauna surveillance</p> <p>S5: Marine fauna impact assessment</p> <p><i>Note:</i></p> <p><i>Aerial surveillance requirements are detailed within the Monitor and Evaluate response within the OPEP</i></p> <p><i>Oiled, injured, and diseased fauna handling to be undertaken by trained personnel resources are</i></p>	<p>Two Study Leads (one for seabirds/shorebirds and one for marine megafauna (marine mammals, sharks, reptiles):</p> <ul style="list-style-type: none"> Bachelor degree in environmental science/engineering (or equivalent) >10 years' experience in environmental practice Familiar OSMP and OPEP, as relevant 	<p>Four vessel personnel:</p> <ul style="list-style-type: none"> Bachelor degree in environmental science/engineering or equivalent >5 years' experience in environmental practice Experienced in the relevant sampling and/or recording techniques Familiar with fauna observation and recording techniques <p>One of the vessel personnel:</p> <ul style="list-style-type: none"> Familiar with tissue sampling, storage and preservation <p>One of the vessel personnel:</p> <ul style="list-style-type: none"> Experienced with ROV/UVA scopes <p>Four field personnel seabird/shorebird:</p> <ul style="list-style-type: none"> Bachelor degree in environmental science/engineering or equivalent >5 years' experience in environmental practice 	<p>One Vessel</p> <p>Two vehicles</p>

Addendum 2: Thylacine Installation and Commissioning EP

Scope Description	Operational / Scientific Study	Study Lead	Field / Office Personnel	Platform
			<ul style="list-style-type: none"> • Bachelor degree in environmental or social science or equivalent • >10 years' experience in environmental practice • Experienced in interpretation and management of heritage, social and economic data <p>Two office personnel:</p> <ul style="list-style-type: none"> • Bachelor degree in environmental science/engineering or equivalent • >5 years' experience in environmental practice 	

Operational and Scientific Monitoring Plan

Addendum 2: Thylacine Installation and Commissioning EP

CDN/ID S4111AF725810.1

Table 4-4: Permits that may be required for scientific monitoring

Permit	Relevance	Legislation	Government Agency
Commonwealth			
General Permit Application for: <ul style="list-style-type: none"> • threatened species and ecological communities • migratory species • whales and dolphins • listed marine species 	Required for matters for scientific sampling for matters listed under the <i>Environment Protection and Biodiversity Conservation Act 1999</i> (EPBC Act)	EPBC Act	Department of Climate Change, Energy, the Environment and Water (DCCEEW)
Access to Biological Resources in a Commonwealth Area for Non-Commercial Purposes	An applicant must obtain written permission from each Access Provider. The Access Provider must state permission for the applicant to: <ul style="list-style-type: none"> • enter the Commonwealth area • take samples from the biological resources of the area • remove samples from the area 	EPBC Act	DCCEEW
Victoria			
Application for a scientific permit to conduct research in areas managed under the <i>National Parks Act 1975</i>	Required for any research activity in marine and intertidal parks protected under Victorian legislation	<i>National Parks Act 1975</i>	Department of Environment, Land, Water and Planning (DELWP)
Application for a scientific permit	Required for any research involving fauna subject to the <i>Wildlife Act 1975</i>	<i>Wildlife Act 1975</i>	DELWP
Tasmania			
Application for a scientific permit to collect or disturb native fauna	A scientific permit is usually required for any research involving the collection or disturbance of protected wildlife, and the collection of protected wildlife products in Tasmania.	<i>Nature Conservation Act 2002</i>	Department of Primary Industries, Parks, Water and the Environment (DPIPWE)
Fishery Permit Application	A Fishery Permit Application is required for the taking of marine fish (including marine invertebrates) for scientific research.	<i>Living Marine Resources Management Act 1995</i>	DPIPWE

Addendum 2: Thylacine Installation and Commissioning EP

Permit	Relevance	Legislation	Government Agency
Animal Ethics Committee approval	If intending to take or disturb living vertebrate or higher invertebrate wildlife, then Animal Ethics Committee approval from a licensed institution is required.	<i>Animal Welfare Act 1993</i>	DPIPWE

Appendix A Scientific Monitoring Priority Planning Area Summaries

A. 1. Apollo Marine Park

Element	Description	
Potential oil exposure	Surface, Entrained, Dissolved	
Priority scientific studies	S1: Water quality impact assessment	Refer to Appendix B for SOP Given location of Marine Park in relation to the spill source, a linear / grid sampling design is considered appropriate, including samples from both within and external to the boundaries of the Marine Park Sample design to be confirmed by Monitoring Provider prior to implementation
	S2: Sediment quality impact assessment	Refer to Appendix B for SOP Given location of Marine Park in relation to the spill source, a linear / grid sampling design is considered appropriate, including samples from both within and external to the boundaries of the Marine Park Sample design to be confirmed by Monitoring Provider prior to implementation
Other scientific studies that may be implemented at the site	S3: Subtidal habitats impact assessment	SOP to be developed post-spill; refer to Offshore Victoria OSMP for relevant guides
	S5: Marine fauna impact assessment	SOP to be developed post-spill; refer to Offshore Victoria OSMP for relevant guides
	S7: Heritage and socioeconomic impact assessment	SOP to be developed post-spill; refer to Offshore Victoria OSMP for relevant guides
Management Plans	South-east Commonwealth Marine Reserves Network Management Plan 2013-2023	Strategy 3 is based on protection of conservation values from detrimental impacts from environmental incidents; includes requirements for reporting and collaboration with government agencies during response Listed outcomes include: <ul style="list-style-type: none"> Impacts associated with environmental incidents are identified and managed appropriately. Systems for timely reporting of and collaboration on responses to environmental incidents are effective
	Approved Conservation Advice for Giant Kelp Marine Forests of South East Australia	Change in water quality (although listed from other sources) is identified as a threat No specific actions for a post-impact change in water quality listed General actions to monitor changes in condition and extent

A. 2. Twelve Apostles Marine National Park

Element	Description	
Potential oil exposure	Shoreline, Entrained, Dissolved	
Priority scientific studies	S1: Water quality impact assessment	Refer to Appendix B for SOP Given location of Marine Park in relation to the spill source, a linear / grid sampling design is considered appropriate, including samples from both within and external to the boundaries of the Marine Park Sample design to be confirmed by Monitoring Provider prior to implementation
	S2: Sediment quality impact assessment	Refer to Appendix B for SOP Given location of Marine Park in relation to the spill source, a linear / grid sampling design is considered appropriate, including samples from both within and external to the boundaries of the Marine Park If shoreline sampling is required, cross-shore beach profiles from intertidal to above high-water mark Sample design to be confirmed by Monitoring Provider prior to implementation
Other scientific studies that may be implemented at the site	S3: Subtidal habitats impact assessment	SOP to be developed post-spill; refer to Offshore Victoria OSMP for relevant guides
	S4: Intertidal habitats impact assessment	SOP to be developed post-spill; refer to Offshore Victoria OSMP for relevant guides
	S5: Marine fauna impact assessment	SOP to be developed post-spill; refer to Offshore Victoria OSMP for relevant guides
Management Plans	S7: Heritage and socioeconomic impact assessment	SOP to be developed post-spill; refer to Offshore Victoria OSMP for relevant guides
	Twelve Apostles Marine National Park and the Arches Marine Sanctuary Management Plan	No specific management actions
	Approved Conservation Advice for Giant Kelp Marine Forests of South East Australia	Change in water quality (although listed from other sources) is identified as a threat Priority actions include those around habitat loss, disturbance and modification; including monitoring progress of recovery through mapping, extent and condition assessments

A. 3. Princetown Wetlands

Element	Description	
Potential oil exposure	Shoreline, Entrained, Dissolved	
Priority scientific studies	S1: Water quality impact assessment	Refer to Appendix B for SOP Given location of wetland in relation to the spill source, a linear sampling design is considered appropriate, with samples taken along an inshore-offshore gradient and including samples from both within and external to the boundaries of the wetland Sample design to be confirmed by Monitoring Provider prior to implementation
	S2: Sediment quality impact assessment	Refer to Appendix B for SOP Given location of wetland in relation to the spill source, a linear sampling design is considered appropriate, with samples taken along an inshore-offshore gradient and including samples from both within and external to the boundaries of the wetland If shoreline sampling is required, cross-shore beach profiles from intertidal to above high-water mark Sample design to be confirmed by Monitoring Provider prior to implementation
Other scientific studies that may be implemented at the site	S4: Intertidal and coastal habitats impact assessment	SOP to be developed post-spill; refer to Offshore Victoria OSMP for relevant guides
	S5: Marine fauna impact assessment	SOP to be developed post-spill; refer to Offshore Victoria OSMP for relevant guides
	S7: Heritage and socioeconomic impact assessment	SOP to be developed post-spill; refer to Offshore Victoria OSMP for relevant guides
Management Plans	Conservation Advice for Subtropical and Coastal Saltmarsh	Pollution from oil spill events are identified as a threat Actions for this TEC include identifying coastal saltmarsh as important habitat in all oil spill contingency planning and monitor the application of protocols on the management of spills involving saltmarshes
	Approved Conservation for the Assemblages of species associated with open-coast salt-wedge estuaries of western and central Victoria ecological community	Change in water quality (although listed from other sources) is identified as a threat No specific actions for a post-impact change in water quality listed General activities to monitor changes in condition

Appendix B Standard Operating Procedures for Water and Sediment Sampling

The Monitoring Provider will review and confirm / update these SOP to ensure they are fit for purpose for the nature and scale of the spill event prior to the SAP being finalised and sampling commencing.

B. 1. Water Sampling – Surface Waters

The number of water samples will be determined on an ad hoc basis, depending on the nature of the spill, the distribution of the spill in relation to sensitive receivers, the availability of resources on site (i.e. vessel availability) and coordination with others responding to the spill (e.g. Australian Maritime Safety Authority).

Triplicate seawater samples will be collected from impact and control sites. Surface water samples will be collected using a marine grade stainless steel bucket from an available support vessel. Subsurface water samples will be collected using Niskin bottles deployed to the appropriate sample depth. The appropriate sample depth should be determined on site in consultation with other agencies, with regard to the modelled distribution of entrained hydrocarbons and a consideration of potential sensitive receivers. Samples will be collected at a range of depths. As a minimum, samples will be collected from 0.5 m below the surface, 0.5 m above the seabed, and in mid water.

Surface water sampling should be conducted as per the following instructions:

1. Prior to deployment, liaise with the vessel crew to ensure that all personnel are familiar with the planned operation.
2. After reviewing the Decon 90 Material Safety Data Sheet (MSDS), clean the sampling bucket using Decon 90, ensuring you are wearing appropriate PPE, including:
 - a. high visibility clothing
 - b. safety boots
 - c. Personal Floatation Device (PFD) if working on the deck
 - d. hard hat (if working on the deck)
 - e. safety glasses
 - f. nitrile gloves.
3. Rinse the sample bucket thoroughly with deionised water once cleaned with Decon 90.
4. Confirm with the deck supervisor and vessel master that the vessel is on station and is prepared for sampling to proceed.
5. Ensure the sampling location is free of potential sources of contamination, including:
 - a. grease and oils
 - b. overhead wires
 - c. exhaust fumes (e.g. incinerators, engine exhaust, cigarette smoke, etc.)
 - d. vessel discharges (e.g. ballast water, grey water, sullage, etc.)
6. Ensure the sampling location is free of entanglement risks (e.g. propellers, thrusters, etc.).
7. Ensure the sampling location is safe (guard rails in place, life ring available), and that weather conditions are suitable for sampling.
8. Prepare the sample containers by labelling them appropriately and completing any required field documentation.
9. Ensure one end of the rope is securely attached to the sampling bucket and the other end to the vessel.
10. Lower the bucket into the water, let the bucket fill and haul it back on board.
11. Once the sample is on board, put on a clean pair of nitrile gloves and collect the water samples using the laboratory sample containers provided. Attempt to collect primarily water in the larger bottles and primarily oil in the smaller bottle. Do not sample rinse the bottles and cap them immediately upon collecting the sample.
12. Once collected, ensure that samples are clearly labelled and stored in the refrigerator.
13. Clean the sampling bucket using Decon 90 (see item 2 above for details) and rinse with deionised water.

B. 2. Water Sampling – Subsurface Waters

Subsurface water sampling will be conducted using Niskin bottles, deployed at appropriate depths. The three 10 L Niskin bottles have Teflon coating and external springs making them suitable for trace and heavy metals and hydrocarbons. The number of Niskin bottles casts and the amount of bulk water needed will depend on the sampling design. Ensure all staff review and sign the water quality sampling JHA.

Niskin samples will be collected in accordance with the following procedure:

1. Prior to deployment, liaise with the vessel crew to ensure that all personnel are familiar with the planned operation.
2. After reviewing the Decon 90 Material Safety Data Sheet (MSDS), clean the Niskin bottles using Decon 90, ensuring you are wearing appropriate PPE, including:
 - a. high visibility clothing
 - b. safety boots
 - c. Personal Floatation Device (PFD) if working on the deck
 - d. hard hat (if working on the deck)
 - e. safety glasses
 - f. nitrile gloves
3. Rinse the Niskin bottles thoroughly with deionised water once cleaned with Decon 90. If possible, fill the Niskin bottles with uncontaminated seawater and allow them to sit prior to sampling.
4. Confirm with the deck supervisor and vessel master that the vessel is on station and is prepared for sampling to proceed.
5. Ensure the sampling location is free of potential sources of contamination, including:
 - a. grease and oils
 - b. overhead wires
 - c. exhaust fumes (e.g. incinerators, engine exhaust, cigarette smoke etc.)
 - d. vessel discharges (e.g. ballast water, grey water, sullage, etc.).
6. Ensure the sampling location is free of entanglement risks (e.g. propellers, thrusters, etc.).
7. Ensure the sampling location is safe (guard rails in place, life ring available), and that weather conditions are suitable for sampling.
8. Ensure one end of the rope is securely attached to the sampling bucket and the other end to the vessel.
9. Ensure the winch line is clean, smooth and has no broken wires or other things that could obstruct the messenger going down the line.
10. Attach the clump weight to the end of the winch line, approx. 10 – 20 kg (consider current at site).
11. Attach the bottom or deepest bottle 1.5–3 m above the weight.
12. Ensure top air bleed is closed, nozzle is pulled out and the bottle is open or set to sample.
13. Before firing the bottles at depth, allow the bottles to flush with sea water for 1–2 minutes at the sample depth.
14. Send the messenger down the line with enough force that it is going to travel directly down the line.
15. You can keep your hand on the line to feel each bottle close. You should be able to feel a tug on the line as the bottle fires.
16. Raise winch line slowly to retrieve bottles.
17. Take care when removing bottles from the winch line as they will be heavy, and care should be taken not to accidentally open the bottles.
18. Decant sea water from the Niskin bottle directly into sample containers.
19. When using carboys, carboys should be rinsed three times with a small amount of the sample water prior to filling with the sample.
20. Prepare the sample containers by labelling them appropriately and completing any required field documentation.
21. Lower the bucket into the water, let the bucket fill and haul it back onboard.

Addendum 2: Thylacine Installation and Commissioning EP

22. Once the sample is onboard, put on a clean pair of nitrile gloves and collect the water samples using the laboratory sample containers provided. Attempt to collect primarily water in the larger bottles and primarily oil in the smaller bottle. Do not sample rinse the bottles and cap them immediately upon collecting the sample.
23. Once collected, ensure samples are clearly labelled and stored in a refrigerator.
24. Clean the sampling bucket using Decon 90 (see item 2 above for details) and rinse with deionised water.

B. 3. Sediment Sampling

Sediment samples will be collected using a van Veen sediment grab (or similar sediment sampling device). Prior to taking a grab sample clean the grab using detergent and a scrubbing brush. Be sure to remove any material adhering to the grab. Ensure all staff review and sign the grab sampling JHA. Sediment samples will be collected in accordance with the following procedure:

Note that the vessel crew will operate the grab with assistance from RPS staff and the winch will be operated by vessel crew. Prior to taking a grab sample clean the grab using detergent and a scrubbing brush. Be sure to remove any material adhering to the grab.

1. Prior to deployment, liaise with the vessel crew to ensure that all personnel are familiar with the planned operation and that clear lines of communication are available.
2. Prepare the grab on the deck, making sure it is securely attached to the vessel winch cable. Mouse any shackles to ensure pin does not come undone under load. Be VERY careful around the grab - always keep clear of the grab jaws. Assume that they may trigger at any time.
3. Take care when the grab is off the deck. NEVER stand under the grab. Check all shackles, etc. before lifting grab off deck. Use strops if required to stabilise the grab.
4. Lower the grab to the seabed, it will trigger when the cable goes slack.
5. Bring the grab to the surface and ensure the sample is sufficient. If the grab begins to swing, lower the grab into the sea to dampen the motion.
6. Open the jaws of the grab slightly to allow emptying of surplus water from the sediment sample but try not to let the fine sediments wash away.
7. Once drained of all free water, open grab completely and empty contents onto a tarpaulin on the deck. Note: due to the mechanics of the grab when opening, surface sediments may be concentrated towards the middle of the sample.
8. Collect a sample of the surface sediments by scraping the 250 ml sample jars through the sediments. Be mindful of contamination sources and ensure that all staff handling samples are wearing clean nitrile gloves.
9. Securely stow the grab onboard when not in use.

B. 4. Cleaning and Care

Niskin bottles should be cleaned with Decon 90 before the sampling trip. Once in the field the bottles should be soaked in sea water. This can be done by attaching the Niskin bottles to the winch line and lowering off the vessel. If time permits, allow the bottles to soak for at least one hour. Avoid touching the internal parts of the Niskin bottle or sampling bucket. Ideally Niskin bottles should be stored upright in racks on the vessel. Take care to store equipment away from potential sources of contamination.

B. 5. Chain of Custody

All samples submitted for analysis will be accompanied by a Chain of Custody (CoC) form. The CoC form will accompany samples during transport and delivery. The form will be signed with the time and date recorded by each individual responsible for the samples including RPS staff and laboratory personnel. Upon each exchange, the CoC form is countersigned and duplicated by the relinquisher. The recipient retains the original. When samples are received by the

Addendum 2: Thylacine Installation and Commissioning EP

laboratory, a duplicate of the original will be issued to RPS confirming arrival. The CoC allows RPS to track the samples and ensure that samples arrive at the intended destinations on schedule.

B. 6. Sample Transport and Storage

Water and sediment samples should be transported as soon as practicable to a nominated laboratory (refer to the OSMP Implementation Plan) in appropriate containers (esky) with ice bricks. The holding times for all samples are 7 days. Samples must be provided to the analytical laboratory within this time period. Liaise with RPS staff regarding sample transport, etc., as outlined in the personnel section of the OSMP Implementation Plan.

The proposed analyses to be undertaken by the primary analytical laboratory are total petroleum hydrocarbons (TPH) and polycyclic aromatic hydrocarbons (PAH) for both sediments and water.



Operational and Scientific Monitoring Plan

Offshore Victoria

Review record (record the last 3 revisions here or the revisions required to achieve current approval version)

Revision	Date	Reason for issue	Reviewer/s	Consolidator	Approver
2	19/12/2019	Issued for NOPSEMA assessment	PW	Xodus	PW
3	31/01/2020	Issued for NOPSEMA assessment	PW	Xodus	PW
4	26/02/2020	Issued for NOPSEMA assessment	PW	Xodus	PW

Review due	Review frequency
Annually from date of acceptance	1 year/s

For internal use and distribution only. Subject to employee confidentiality obligations. Once printed, this is an uncontrolled document unless issued and stamped Controlled Copy or issued under a transmittal.

THE THREE WHATS

What can go wrong?

What could cause it to go wrong?

What can I do to prevent it?

Table of contents

1	Introduction	3
1.1	Purpose	3
1.2	Scope	3
1.2.1	Activities	3
1.2.2	Oil type	3
1.2.3	Geographic extent	4
1.3	Definitions/Acronyms	4
2	OSMP Framework	6
2.1	Overview	6
2.2	Objectives	6
2.3	Types of monitoring	6
2.4	Study design and standard operating procedures	7
2.5	Baseline environmental state	8
2.6	Links to response options	9
2.7	Links to environmental values and sensitivities	9
3	Implementation	14
3.1	Overview	14
3.2	Roles and responsibilities	14
3.3	Capability, training and competency	15
3.3.1	Capability	16
3.3.2	Training and Competency	16
3.4	Monitoring	16
3.5	Communication and notification	19
3.6	Review and revisions	19
3.7	Environmental Performance Outcomes	19
4	Operational Monitoring	21
4.1	Overview	21
4.1.1	General design considerations	21
4.2	Study O1: Oil characterisation and behaviour	22
4.3	Study O2: Water quality	23
4.4	Study O3: Sediment quality	25
4.5	Study O4: Marine fauna surveillance	27
4.6	Study O5: Dispersant efficacy	28
4.7	Study O6: Fish tainting	30
5	Scientific Monitoring	32
5.1	Overview	32
5.1.1	General design considerations	32
5.2	Study S1: Water quality impact assessment	33
5.3	Study S2: Sediment quality impact assessment	35
5.4	Study S3: Subtidal habitats impact assessment	38
5.5	Study S4: Intertidal and coastal habitats impact assessment	41
5.6	Study S5: Marine fauna impact assessment	43

5.7	Study S6: Fisheries impact assessment	46
5.8	Study S7: Heritage and socioeconomic impact assessment	48
6	References/Associated documents	51
7	Document information and history	53

Table of figures

Figure 3-1:	Implementation process for operational and scientific monitoring	18
-------------	--	----

List of tables

Table 2-1:	Study scopes appropriate for post-spill pre-impact sampling (reactive baseline)	8
Table 2-2:	Operational monitoring and response strategies	9
Table 2-3:	Environmental values and sensitivities and related operational and scientific monitoring studies	10
Table 3-1:	Roles and responsibilities for OSMP implementation	14
Table 3-2:	Environmental Performance Outcomes, Standards and Measurement Criteria	20

List of appendices

Appendix A	Approaches for Scientific Monitoring Design	54
A. 1.	Before-After-Control-Impact (BACI) approach	54
A. 2.	Impact versus Control (IvC) approach	56
A. 3.	Gradient approach	56
A. 4.	Control chart approach	57
A. 5.	Lines of evidence approach	58
Appendix B	Baseline Information	61

1 Introduction

1.1 Purpose

This Offshore Victoria Operational and Scientific Monitoring Plan (OSMP) provides the framework for environmental monitoring response to Level 2 and Level 3 offshore oil spills from petroleum activities undertaken by Beach Energy Ltd (Beach) in the Otway and Bass Basins.

The OSMP is a component of the environmental management framework, which also includes activity specific Environment Plans (EP), the Offshore Victoria – Otway Basin Oil Pollution Emergency Plan (OPEP) (CDN/ID S4100AH717907) and the BassGas Offshore OPEP (CDN/ID 3972816).

The OSMP has been developed to satisfy the requirements of Regulation 14(8AA) and 14(8D) of the Commonwealth *Offshore Petroleum and Greenhouse Gas Storage (Environment) Regulations 2009* (OPGGs(E)R), Regulation 16 of the Victorian *Offshore Petroleum and Greenhouse Gas Storage Regulations 2011* (OPGGsR) and Regulation 19 of the Tasmanian *Petroleum (Submerged Lands) (Management of Environment) Regulations 2012* (P(SL)(ME)R).

The OSMP is to be read in conjunction with the relevant EP, OPEP and OSMP Addendum when considering the existing environment, values and sensitivities, credible oil spill risks and potential impacts, response activities and the decision processes that will apply in the event that a spill occurs. The relevant EP also describes any related performance standards, notification requirements and/or reporting compliance.

1.2 Scope

1.2.1 Activities

This OSMP is relevant to all Beach petroleum activities within the Otway and Bass Basins regulated under the Commonwealth OPGGS(E)R, Victorian OPGGSR and Tasmanian P(SL)(ME)R. This includes, but is not limited to the following activity types:

- Operation of a facility or pipeline
- Vessel activities
- Drilling.

1.2.2 Oil type

Spill risks from the above activities that could result in a Level 2 or Level 3 spill event include two oil types:

- Gas condensate
- Marine diesel.

This OSMP is relevant to all oil types and states (i.e. fresh and weathered); and all distributions throughout the environment (e.g. surface, entrained, dissolved and shoreline).

1.2.3 Geographic extent

This OSMP is relevant and applicable to all Commonwealth and State marine and coastal areas that are potentially at risk of exposure to oils in the event of a Level 2 or Level 3 spill resulting from Beach's petroleum activities within the Otway and Bass Basins.

The spatial extent of any particular operational or scientific monitoring study will depend on the actual and/or potential area exposed by an individual spill event. Therefore, monitoring extent would only be finalised once a spill event has occurred and be at a sufficient scale to meet monitoring objectives.

1.3 Definitions/Acronyms

Definitions of terms used in this plan:

Terms/acronym	Definition/expansion
AMSA	Australian Maritime Safety Authority
ANOVA	Analysis of variance
ANZECC	Australian and New Zealand Environment and Conservation Council
ANZG	Australian and New Zealand Governments
API	American Petroleum Institute
ARMCANZ	Agriculture and Resource Management Council of Australia and New Zealand
BACI	Before After Control Impact
Beach	Beach Energy Ltd
Control Agency	The Control Agency for an oil spill response is the government agency or company assigned by legislation, administrative arrangement or within the relevant contingency plan to control response activities to an oil spill
DJPR	(Victoria) Department of Jobs, Precincts and Regions
DPIPWE	(Tasmania) Department of Primary Industries, Parks, Water and Environment
EP	Environment Plan
EPBC Act	(Commonwealth) Environment Protection and Biodiversity Conservation Act 1999
EMBA	Environment that may be Affected
EMLO	Emergency Management Liaison Officer
EMT	Emergency Management Team
EUL	Environment Unit Lead
HSE	Health, Safety and Environment
Incident Controller	The individual responsible for the management of all incident control activities across an incident (Note: for spill events where Beach is the Control Agency, this is the equivalent of the EMT Leader)
IMT	Incident Management Team
IvC	Impact versus Control
LCL	Lower control limit
LEL	Lower explosive limit

Terms/acronym	Definition/expansion
Level 2	Level 2 incidents are more complex in size, duration, resource management and risk and may require deployment of jurisdiction resources beyond the initial response (as per NatPlan)
Level 3	Level 3 incidents are generally characterised by a degree of complexity that requires the Incident Controller to delegate all incident management functions to focus on strategic leadership and response coordination and may be supported by national and international resources (as per NatPlan)
MBACI	Multiple Before After Control Impact
MNES	Matters of national environmental significance
Monitoring Provider	Service provider for environmental monitoring studies; may be one or multiple companies (as required)
NATA	National Association of Testing Authorities
NatPlan	National Plan for Maritime Environmental Emergencies
NOAA	(United States) National Oceanic and Atmospheric Administration
NOPSEMA	National Offshore Petroleum Safety and Environmental Management Authority
OPGGG(E)R	(Commonwealth) Offshore Petroleum and Greenhouse Gas Storage (Environment) Regulations 2009
OPGGSR	(Victoria) Offshore Petroleum and Greenhouse Gas Storage Regulations 2011
OSMP	Operational and Scientific Monitoring Plan
OSRL	Oil Spill Response Limited
OPEP	Oil Pollution Emergency Plan
PAH	Polycyclic aromatic hydrocarbons
PERMANOVA	Permutational multivariate analysis of variance
PSD	Particle size distribution
P(SL)(ME)R	(Tasmania) Petroleum (Submerged Lands) (Management of Environment) Regulations 2012
Ramsar	Convention on wetlands of international importance
SAP	Sampling and Analysis Plan
SD	Standard deviation
SMART	Special Monitoring of Applied Response Technologies
SME	Subject Matter Expert
SOP	Standard operating procedures
SGGV	Sediment quality guideline value
Statutory Authority	The Statutory Authority has the statutory responsibility for marine pollution incidents in their area of jurisdiction
TOC	Total organic carbon
TPH	Total petroleum hydrocarbon
UCL	Upper control limit
USEPA	United States Environment Protection Authority
VOC	Volatile organic compound

2 OSMP Framework

2.1 Overview

This OSMP provides the framework for Beach's environmental monitoring response to Level 2 and Level 3 offshore oil spills from their petroleum activities undertaken in the Otway and Bass Basins.

This OSMP lists a series of possible studies (with types of sampling techniques and parameters) that may be undertaken in the event of a spill. This OSMP is not intended to be prescriptive, but to provide a flexible framework such that the finalised monitoring studies are fit for purpose and tailored to the specific location, oil type, environmental sensitivities, and the nature and scale of the individual spill.

This OSMP incorporates regulatory guidance from the following documents:

- Guidance note – Oil pollution risk management (NOPSEMA 2018)
- Information paper – Operational and scientific monitoring programs (NOPSEMA 2016).

2.2 Objectives

The objectives of this OSMP are:

- Identify and describe the operational and scientific monitoring that may be implemented in the event of a Level 2 or Level 3 oil spill to the marine or coastal environment
- Demonstrate an appropriate degree of readiness to implement this monitoring in the event of an oil spill to the marine or coastal environment.

2.3 Types of monitoring

Oil spill monitoring has been divided into two types, operational and scientific, which are undertaken for two distinct, but closely related, purposes (NOPSEMA 2016).

Operational monitoring (also known as Type I or response phase monitoring) which collects information about the spill and associated response activities to aid planning and decision making during the response or clean-up operations. Operational monitoring may include both initial response phase monitoring (i.e. rapid qualitative and observational data gathering for situational awareness) and advanced response phase monitoring (i.e. quantitative measurement) (Hook et al. 2016). Operational monitoring typically finishes when the spill response is terminated.

Six operational monitoring studies have been identified (see Section 4):

- O1: Oil characterisation and behaviour
- O2: Water quality
- O3: Sediment quality
- O4: Marine fauna surveillance
- O5: Dispersant efficacy

- O6: Fish tainting.

Operational monitoring studies complement the Monitoring and Evaluate response strategy described in the relevant OPEP. This response strategy may include spatial surveillance techniques and spill trajectory predictions. Operational monitoring (e.g. Study O5) can also be directly related to a particular response strategy (i.e. Chemical Dispersants) (see Section 2.4).

Scientific monitoring (also known as Type II or recovery phase monitoring) which is focussed on non-response objectives and evaluating environmental impact and recovery from both the spill event itself as well as from any response activities. Results from scientific monitoring studies may also be used to identify and recommend remediation requirements where required. Scientific monitoring may continue for extended periods after a spill response is terminated.

Seven scientific monitoring studies have been identified (see Section 5):

- S1: Water quality impact assessment
- S2: Sediment quality impact assessment
- S3: Subtidal habitats impact assessment
- S4: Intertidal and coastal habitats impact assessment
- S5: Marine fauna impact assessment
- S6: Fisheries impact assessment
- S7: Heritage and socioeconomic impact assessment.

Operational and scientific monitoring studies may occur simultaneously (i.e. scientific monitoring can start before a response operation is completed). There may also be an information flow between studies, for example data from operational monitoring may be used to trigger the initiation of scientific studies.

Different oil types, spill locations, and volumes require different studies to form a fit-for-purpose operational and scientific monitoring program that is able to determine the extent, severity and persistence of environmental impacts from the oil spill.

2.4 Study design and standard operating procedures

Where appropriate, sampling design and procedures will be aligned with existing standards or guidance notes. These include, but are not limited to:

- Oil Spill Monitoring Handbook (Hook et al. 2016)
- Australian and New Zealand Water Quality Guidelines for Fresh and Marine Waters Quality (ANZG 2018)
- Parks Victoria Standard Operating Procedure for Biological Monitoring of Subtidal Reefs (Edmunds and Hart 2005)
- Parks Victoria Standard Operating Procedure for Biological Monitoring of Intertidal Reefs (Hart and Edmunds 2005)
- Industry Recommended Subsea Dispersant Monitoring Plan (American Petroleum Institute 2013)

- Dispersant Application Monitoring Field Guide Tier I Visual Observation (OSRL 2011)
- Special Monitoring of Applied Response Technologies (NOAA 2006).

References to relevant standard operating procedures are provided within study tables in Section 4 and 5.

Consideration has also been given to the scopes and procedures within the Industry OSMP that is currently under preparation by APPEA (APPEA 2019).

2.5 Baseline environmental state

Baseline monitoring provides information on the condition of ecological receptors prior to or spatially independent (e.g. if used in control chart analyses) of a spill event. This is of importance for scientific monitoring where the ability to detect changes between pre-impact and post-impact conditions is necessary.

Given the large aerial extents of predicted oil exposure (or EMBA) from worst-case spill scenarios, and the inherent spatial and temporal variability in the environment, an ongoing or pre-impact baseline monitoring program is not planned.

However, Appendix B provides a database of known literature and studies relevant to environmental receptors within the Otway and Bass Basins that may provide suitable baseline data and/or contextual information in the event of a spill.

In addition, there are also operational and scientific monitoring studies that are suited to pre-impact baseline monitoring (Table 2-1). Therefore, in the event of a Level 2 or Level 3 oil spill, reactive pre-impact monitoring should, where practicable, be implemented to gather additional data on the current state of the environment.

Table 2-1: Study scopes appropriate for post-spill pre-impact sampling (reactive baseline)

Study	Pre-impact sampling	Post-impact sampling
Operational monitoring		
O1: Oil characterisation and behaviour		✓
O2: Water quality	✓	✓
O3: Sediment quality	✓	✓
O4: Marine fauna surveillance		✓
O5: Dispersant efficacy		✓
O6: Fish tainting		✓
Scientific monitoring		
S1: Water quality impact assessment	✓	✓
S2: Sediment quality impact assessment	✓	✓
S3: Subtidal habitats impact assessment	✓	✓
S4: Intertidal and coastal habitats impact assessment	✓	✓
S5: Marine fauna impact assessment	✓	✓
S6: Fisheries impact assessment		✓
S7: Heritage and socioeconomic impact assessment	✓	✓

2.6 Links to response options

The objectives of individual operational monitoring studies are typically associated with one or more specific response strategies (Table 2-2).

Table 2-2: Operational monitoring and response strategies

Response strategy	Study O1 Oil characterisation and behaviour	Study O2 Water quality	Study O3 Sediment quality	Study O4 Marine fauna surveillance	Study O5 Dispersant efficacy	Study O6 Fish tainting
Source control	✓	✓	✓			
Monitor and evaluate	✓	✓	✓	✓		✓
Assisted natural dispersion	✓	✓		✓		✓
Chemical dispersants	✓	✓	✓		✓	✓
Containment and recovery	✓			✓		
Protection and deflection	✓	✓	✓	✓		
Shoreline clean-up	✓		✓	✓		
Oiled wildlife response	✓			✓		

2.7 Links to environmental values and sensitivities

The types of environmental values and sensitivities (including matters of national environmental significance) known to occur in the Otway and Bass Basins and the related operational and scientific monitoring studies area shown in Table 2-3.

For the identification and descriptions of values and sensitivities present within an environment that may be affected (EMBA) for a particular activity, refer to the description in the relevant EP.

For an identification of key areas at risk, the associated environmental values and sensitivities and the links to relevant operational and scientific monitoring studies, refer to the relevant OSMP Addendum.

Table 2-3: Environmental values and sensitivities and related operational and scientific monitoring studies

Environmental value and sensitivities	Matters of national environmental significance	Value or sensitivity present in region		Operational Monitoring							Scientific Monitoring						
		Otway Basin	Bass Basin	Study O1	Study O2	Study O3	Study O4	Study O5	Study O6	Study S1	Study S2	Study S3	Study S4	Study S5	Study S6	Study S7	
Protected areas																	
Australian Marine Parks	✓ ¹	✓	✓		✓	✓	✓			✓		✓		✓		✓	
State marine protected areas		✓	✓		✓	✓	✓			✓	✓	✓	✓	✓		✓	
State terrestrial protected areas		✓	✓			✓	✓				✓			✓		✓	
Wetlands of international importance (Ramsar wetlands)	✓	✓	✓		✓	✓	✓				✓		✓	✓		✓	
Ecological features																	
Key ecological features	2	✓	✗		✓					✓		✓					
Threatened ecological communities	✓	✓	✓		✓							✓	✓				

Environmental value and sensitivities	Matters of national environmental significance	Value or sensitivity present in region		Operational Monitoring							Scientific Monitoring					
		Otway Basin	Bass Basin	Study O1	Study O2	Study O3	Study O4	Study O5	Study O6	Study S1	Study S2	Study S3	Study S4	Study S5	Study S6	Study S7
				Oil characterisation and behaviour	Water quality	Sediment quality	Marine fauna surveillance	Dispersant efficacy	Fish tainting	Water quality impact assessment	Sediment quality impact assessment	Subtidal habitats impact assessment	Intertidal and coastal habitats impact assessment	Marine fauna impact assessment	Fisheries impact assessment	Heritage and socioeconomic impact assessment
Threatened and migratory species	✓	✓	✓				✓							✓		
Invertebrates		✓	✓											✓	✓	
Fish		✓	✓											✓	✓	
Sharks		✓	✓				✓							✓		
Cetaceans		✓	✓				✓							✓		
Pinnipeds		✓	✓				✓							✓		
Turtles		✓	✓				✓							✓		
Birds		✓	✓				✓							✓		
Subtidal benthic habitats		✓	✓									✓				
Intertidal benthic habitats		✓	✓										✓			
Wetlands of national importance		✓	✓		✓	✓	✓						✓	✓		

Environmental value and sensitivities	Matters of national environmental significance	Value or sensitivity present in region		Operational Monitoring						Scientific Monitoring						
		Otway Basin	Bass Basin	Study O1	Study O2	Study O3	Study O4	Study O5	Study O6	Study S1	Study S2	Study S3	Study S4	Study S5	Study S6	Study S7
				Oil characterisation and behaviour	Water quality	Sediment quality	Marine fauna surveillance	Dispersant efficacy	Fish tainting	Water quality impact assessment	Sediment quality impact assessment	Subtidal habitats impact assessment	Intertidal and coastal habitats impact assessment	Marine fauna impact assessment	Fisheries impact assessment	Heritage and socioeconomic impact assessment
Cultural and heritage features																
World Heritage properties	✓	✗	✗													✓
Commonwealth Heritage places		✗	✓		✓	✓	✓				✓		✓			✓
National Heritage places	✓	✓	✓		✓	✓	✓				✓		✓			✓
Indigenous Protected Areas		✓	✓			✓					✓		✓			✓
Areas of Aboriginal cultural heritage sensitivity		✓	✓			✓					✓		✓			✓
Shipwrecks		✓	✓		✓					✓		✓				✓
Socioeconomic features																
Commercial fisheries		✓	✓						✓						✓	

Environmental value and sensitivities	Matters of national environmental significance	Value or sensitivity present in region		Operational Monitoring						Scientific Monitoring						
		Otway Basin	Bass Basin	Study O1	Study O2	Study O3	Study O4	Study O5	Study O6	Study S1	Study S2	Study S3	Study S4	Study S5	Study S6	Study S7
				Oil characterisation and behaviour	Water quality	Sediment quality	Marine fauna surveillance	Dispersant efficacy	Fish tainting	Water quality impact assessment	Sediment quality impact assessment	Subtidal habitats impact assessment	Intertidal and coastal habitats impact assessment	Marine fauna impact assessment	Fisheries impact assessment	Heritage and socioeconomic impact assessment
Tourism and recreation		✓	✓		✓	✓	✓		✓		✓	✓	✓	✓		✓
Coastal settlements		✓	✓		✓	✓					✓		✓	✓		✓
Shipping		✓	✓		✓					✓						✓
Petroleum industry		✓	✓		✓					✓						✓

Notes:

1. Commonwealth marine areas are listed as a MNES under the EPBC Act. Marine protected areas are marine areas which are recognised to have high conservation value.
2. Key ecological features are not MNES and have no legal status in their own right; however, they may be considered as components of the Commonwealth marine area.

3 Implementation

3.1 Overview

This section outlines the following:

- roles and responsibilities for personnel involved in implementing operational and scientific monitoring
- communications and notification to key external stakeholders
- review and revision schedule for this OSMP
- environmental performance outcomes, standards and measurement criteria related to this OSMP.

3.2 Roles and responsibilities

Beach is responsible for the implementation and adherence to the requirements of this OSMP for events where they are the Control Agency. Key roles and responsibilities are identified in Table 3-1. Depending on the scale of the event, individual people may perform multiple roles; similarly, multiple people may share the same role. The Emergency Response Team (EMT) Leader (or delegate) is the key position responsible for overseeing the implementation of this OSMP (Table 3-1).

For oil spill events where the Control Agency is not Beach (e.g. vessel spills in Commonwealth waters), the relevant Control Agency would be responsible for the initiation and implementation of response phase (i.e. operational) monitoring requirements (AMSA 2019). It is noted that implementation may be delegated to another agency or company (including Beach) to provide services. Beach maintains the responsibility to initiate and implement the recovery phase (i.e. scientific) monitoring, in conjunction with support agencies, local government and statutory authorities where relevant.

Where the OSMP is activated the EMT Environment Leader will work in collaboration with the Monitoring Provider Program Manager. The Monitoring Provider Program Manager (over 20 years' experience and training) will manage the monitoring programs advised by Monitoring Provider Study Leads (a monthly log of the Monitoring Provider personnel is provided to Beach to ensure that they have the appropriate levels of training and experience). The Monitoring Provider Study Leads will direct any offshore monitoring that may be required in the event of an oil spill. Beach personnel will provide the resources to allow the monitoring to be undertaken in a safe manner.

Table 3-1: Roles and responsibilities for OSMP implementation

Role	Timing	Responsibilities
Emergency Management Team (EMT) Leader	Emergency response	<ul style="list-style-type: none"> • Overall responsibility for providing and coordinating operational emergency management activities • Equivalent to role of Incident Controller • Overall responsibility for implementation of this OSMP during an oil spill response • Overall responsibility for ensuring safe operations during OSMP implementation
EMT Environment Leader	Emergency response Ongoing	<ul style="list-style-type: none"> • Implementation of the OSMP • Initiation of operational and scientific monitoring studies • Termination of operational and scientific monitoring studies • Interface with EMT, Planning and Logistics Leaders and Monitoring Provider

Role	Timing	Responsibilities
		<ul style="list-style-type: none"> Activation of Monitoring Provider/s Day-to-day coordination of operational and scientific monitoring Review and approval of operational and scientific monitoring plans and data reports Interface with external agencies including NOPSEMA, DJPR and DPIPW
EMT Planning Leader (or delegate)	Emergency response	<ul style="list-style-type: none"> Interface with EMT Environment Leader for OSMP implementation (as required) Provides operational monitoring data to EMT to support response planning
EMT Logistics Leader (or delegate)	Emergency response	<ul style="list-style-type: none"> Interface with EMT Environment Leader for OSMP implementation (as required) Support (as required) for implementing operational monitoring (e.g. site access etc.) Support (as required) for mobilising plant and equipment (e.g. vessels, air support, vehicles etc.)
Emergency Management Liaison Officer (EMLO)	Emergency response	<ul style="list-style-type: none"> Interface between Beach EMT and State Control Agency Incident Management Team (IMT)
Monitoring Provider – Program Manager	Emergency response Ongoing	<ul style="list-style-type: none"> Work in collaboration with the EMT Environment Leader to implement the OSMP studies Interface with Monitoring Provider Study Leads and EMT Environment Leader Manage the monitoring programs advised by Monitoring Provider Study Leads Provide Beach with a monthly log of the Monitoring Provider personnel available to implement the OSMP
Monitoring Provider – Study Lead	Emergency response Ongoing	<ul style="list-style-type: none"> Interface with Monitoring Provider Program Manager and/or EMT Environment Leader Implementation of individual monitoring studies (as required) Prepare monitoring plans and sampling procedures Review and approve data reports Ensure compliance with requirements of this OSMP
Monitoring Provider – Field Personnel	Emergency response Ongoing	<ul style="list-style-type: none"> Undertake field sampling and observations Ensure compliance with requirements of this OSMP
Monitoring Provider – Office Personnel	Emergency response Ongoing	<ul style="list-style-type: none"> Prepare data reports Ensure compliance with requirements of this OSMP

3.3 Capability, training and competency

Personnel involved in implementing this OSMP may be sourced from both internal (i.e. Beach) and external (e.g. Monitoring Provider) resources. The number of personnel needed to fulfil roles for any given event depends on the event's circumstances. Depending on the scale of the event, individual people may perform multiple roles; similarly, multiple people may share the same role.

3.3.1 Capability

A capability needs assessment for the implementation of the OSMP studies is included in the OSMP Addendum specific to each EP's activities and relevant spill scenarios. The capability needs assessment identifies the minimum number of personnel to manage and implement the OSMP studies and the type of platforms (vessel, aircraft or vehicles) required to perform the studies. The studies have been group where appropriate to ensure effective use of resources.

3.3.2 Training and Competency

Training and competency for Beach EMT roles are described within the Offshore Victoria – Otway Basin Oil Pollution Emergency Plan (OPEP) (CDN/ID S4100AH717907) and the BassGas Offshore OPEP (CDN/ID 3972816). This training matrix includes OSMP Awareness training for all relevant personnel.

Minimum competency requirements for individuals to fulfil OSMP-specific roles are identified within the operational and scientific monitoring study tables (Section 4 and 5). Minimum competencies can vary from degree qualified and experienced personnel (e.g. typical requirement for Study Leads) to an awareness level (e.g. typical for immediate response phase field sampling).

3.3.2.1 Internal resources

Internal capability within Beach includes offices and personnel based in Perth (Western Australia), Adelaide (South Australia), Melbourne (Victoria) and New Plymouth (New Zealand). Internal resources with appropriate environmental and/or oil spill response competencies will fulfil the OSMP-related roles of:

- EMT Leader
- EMT Environment Leader.

Internal Beach personnel may also perform Monitoring Provider (Study Lead, Field Personnel and Office Personnel) roles and responsibilities, particularly during first-response operational monitoring.

3.3.2.2 External resources

External personnel will primarily perform Monitoring Provider (Program Manager, Study Lead, Field Personnel and Office Personnel) roles and responsibilities, particularly during scientific monitoring.

External resources and capability are reviewed prior to an activity commencing to ensure appropriate agreements / activations are in place (see Section 3.7).

3.4 Monitoring

This OSMP lists a series of possible operational and scientific monitoring studies (with types of sampling techniques and parameters) that may be undertaken in the event of a spill; these studies are outlined in Sections 4 and 5. This OSMP is not intended to be prescriptive, but to provide a flexible framework such that the finalised monitoring studies are fit for purpose and tailored to the specific location, oil type, environmental sensitivities, and the nature and scale of the individual spill.

In the event of a Level 2 and Level 3 oil spill, a series of steps beginning with the preparation of an appropriate Sampling and Analysis Plan (SAP) is implemented (Figure 3-1). While the decision to initiate and terminate a particular study is the responsibility of Beach (EMT Environment Leader), the SAP, field survey and reporting is primarily undertaken by the

Monitoring Provider (Beach personnel may undertake or assist with operational monitoring, particularly during initial response phase).

Figure 3-1 also shows the flow of information (grey dashed lines) between the operational and scientific monitoring streams and associated OPEP processes.




Figure 3-1: Implementation process for operational and scientific monitoring

3.5 Communication and notification

Stakeholder (including regulators) consultation and external notification requirements are described in the activity-specific EPs. This includes the requirement to consult with:

- Department of Jobs, Precincts and Regions (Victoria) and/or Department of Primary Industries, Parks, Water and Environment (Tasmania), in the event that an oil spill is likely to impact State waters
- Department of the Environment and Energy (DoEE), in the event that an oil spill is likely to impact matters of national environmental significance
- Director of National Parks, in the event that an oil spill and/or response activity are likely to impact an Australian Marine Park.

Consultation may also be undertaken with the above agencies or additional agencies (e.g. Heritage Victoria) in the event of a Level 2 or Level 3 oil spill with respect to input and/or review of a spill-specific Sampling and Analysis Plan (SAP) for scientific monitoring studies.

3.6 Review and revisions

This Offshore Victoria OSMP is subject to review, and revised if necessary, on an annual basis to incorporate the following:

- Significant change in the oil spills risks associated with Beach activities and/or facilities within offshore Victorian waters
- Significant environmentally relevant changes (e.g. changes to relevant legislation, stakeholder information, MNES, State/Commonwealth management plans, or availability of new literature)
- Findings from internal or external audits or exercises
- Lessons learned following any actual spill event.

Review records will be detailed in Beach Document Information and History tables (Section 7). Subsequent revisions to the OSMP (or supporting guides and procedures) will be actioned and closed-out as soon as practicable following the review.

As part an EP, Regulation 19 of the OPGGS(E)R also provides for the revision of the OSMP at least 14 days before the end of the period of five years from the most recent approval of an associated EP.

3.7 Environmental Performance Outcomes

Environmental performance outcomes, standards and measurement criteria related to this OSMP have been defined in Table 3-2.

Table 3-2: Environmental Performance Outcomes, Standards and Measurement Criteria

Environmental Performance Outcome	Control Measure	Environmental Performance Standard	Responsible Person	Measurement Criteria
Undertake oil spill response in a manner that will not result in additional impacts to marine environment, coastal habitat and oiled wildlife.	NOPSEMA accepted Operational and Scientific Monitoring Plan	Operational and scientific monitoring capability shall be maintained in accordance with the OSMP: <ul style="list-style-type: none"> a month prior to the commencement of drilling a review of the contracted OSMP provider/s capability will be undertaken by Beach to ensure that the OSMP requirements can be met by the contracted OSMP provider/s. during drilling the contracted OSMP provider/s will provide a monthly report to show that capability as detailed in the OSMP is maintained. the contracted OSMP provider/s capability to meet the requirements detailed in the OSMP will be tested prior to commencing drilling. 	Senior Crisis, Emergency & Security Advisor	Outcomes of internal audits and tests demonstrate preparedness

4 Operational Monitoring

4.1 Overview

The following sections outline the individual operational monitoring studies that may be implemented in the event of a Level 2 or Level 3 oil spill to the marine or coastal environment. The tables describe the objective, initiation and termination criteria, timing, monitoring (types of sampling techniques and parameters), reporting, resources and competencies.

The studies are presented separately below; however, in practice they may be undertaken simultaneously.

Six operational monitoring studies have been identified:

- O1: Oil characterisation and behaviour
- O2: Water quality
- O3: Sediment quality
- O4: Marine fauna surveillance
- O5: Dispersant efficacy
- O6: Fish tainting.

The operational monitoring studies described in this OSMP complement the Monitor and Evaluate response strategy described in the OPEP in providing information to support decision-making around response activity.

Note: due to the rapid weathering characteristics of gas condensate and marine diesel, operational monitoring studies O1, O2, O3 and O4 are not considered relevant for a pipeline rupture or vessel collision event where there is only a short period of oil release. The time that would elapse between a spill occurring and monitoring personnel being on site would render the data collected unnecessary in informing response strategies. Studies O1, O2, O3 and O4 are, therefore, only actioned (once initiation criteria are met) as a result of a loss of well control incident.

4.1.1 General design considerations

An event-specific sampling and analysis plan (SAP), appropriate to the nature and scale of the event, should be developed and in place before conducting field sampling. The following items should be considered when developing the SAP:

- Nature and scale of the spill (e.g. surface or subsea release, instantaneous or ongoing release, etc.)
- The environment which may be affected (e.g. subtidal or intertidal, depth, presence of other sensitive receptors, etc.)
- Program design aims, which may include but, not limited to the determination of the extent of oil, and the spatial and temporal distribution of the oil
- The sampling plan should have flexibility to be adjusted based on conditions in the field and as new information about the even becomes available

- The number of sites and samples to be collected should be spill-specific and take into account level of effort, potential logistical limitations, weather conditions, sample holding times, freight/transport options etc. that if not properly managed can compromise sample integrity
- Where time permits, appropriate QA/QC samples should be collected to allow assessment of local variability and ascertain potential for introduction of sample contamination throughout the collection and analysis process
- Appropriate QA/QC protocols for sample handling, storage and transport should be included to limit the potential for contamination and ensure sample integrity meets laboratory requirements.
- Monitoring frequency should consider weathering of the spilled oil, with frequency decreasing as the rate of change in the spilled oil decreases (i.e. monitoring effort is concentrated towards the beginning of a spill)
- Subsea sampling in the vicinity of project infrastructure should be designed to avoid damage to or entanglement with this infrastructure
- Health and safety factors associated with working in a range of environments with consideration of prevailing weather.

4.2 Study O1: Oil characterisation and behaviour

An overview of the key components of Study O1 are provided below:

Component	Description
Objective	To provide an assessment of the oil properties and visual observations of the behaviour and weathering of the spilled oil
Initiation trigger	<ul style="list-style-type: none"> • The EMT Environment Leader (or delegate) has confirmed that a Level 2 or Level 3 offshore oil spill has occurred or • The EMT Environment Leader (or delegate) advises that either full or partial implementation of the study is to commence
Termination trigger	<ul style="list-style-type: none"> • Any related scientific monitoring studies have been initiated by the EMT Environment Leader (or delegate) and • The EMT Environment Leader (or delegate) considers that continuation of monitoring under Study O1 will not result in a change to the scale or location of active response options or • The EMT Environment Leader (or delegate) has advised that agreement has been reached with the Jurisdictional Authority relevant to the spill to terminate the response or • The EMT Environment Leader (or delegate) has advised that continuation of monitoring under Study O1 may increase overall environmental impact
Timing	<ul style="list-style-type: none"> • Where required, the Monitoring Provider/s will be activated (refer to the relevant OSMP Addendum for the petroleum activities) within 4 hours of initiation criteria being met • Where required, an initial SAP to be available within 12 hours of initiation criteria being met • Field surveys to commence within 24 hours of initiation criteria being met <p>Note: the initial SAP may be revised as required due to the nature of an ongoing spill event, changing operational requirements and/or results from data collected to date</p> <p>Note: timing of mobilisation and field surveys is dependent on safe operating conditions (e.g. weather, sea state, etc.) and operational access to sites</p>
Sampling Techniques	<p>Sampling techniques will vary depending on the individual event and final monitoring design. The following types of sampling may be implemented under Study O1:</p> <ul style="list-style-type: none"> • Vessel or shore-based

Component	Description
	<ul style="list-style-type: none"> • Collection of an oil sample <ul style="list-style-type: none"> ◦ Surface skimming (sampling pole with container) ◦ Oleophilic absorbent pads • Behaviour and weathering <ul style="list-style-type: none"> ◦ Visual observations
Standard Operating Procedures	<p>The following references are provided as guides for standard operating procedures (SOP) that may be implemented under Study O1:</p> <ul style="list-style-type: none"> • Oil Spill Monitoring Handbook (Hook et al 2016) <p>SOP will be confirmed by the Monitoring Provider during preparation of the Sampling and Analysis Plan (SAP).</p>
Parameters	<p>Sampling parameters will vary depending on the individual event and final monitoring design. The following types of parameters may be analysed under Study O1:</p> <ul style="list-style-type: none"> • Physical properties (e.g. viscosity, pour point, density, wax content) • Chemical properties (e.g. hydrocarbon characterisation, volatile content) • Oil component concentrations (e.g. TRH, BTEX, PAH, MAH) • Visual records of extent and state (e.g. colour/optical effect on surface, form (slick, emulsion, mousse etc), presence waxy residue)
Guidelines	N/A
Reporting	<ul style="list-style-type: none"> • Results from laboratory sampling reported as available to EMT Environment Leader • Final report prepared within one-week of termination criteria being met and report provided to EMT Environment Leader
Key Resources	<ul style="list-style-type: none"> • Monitoring Provider or Responder Personnel • Vessels • Analytical laboratory services
Key Competencies	<ul style="list-style-type: none"> • Monitoring Provider – Study Lead <ul style="list-style-type: none"> ◦ Bachelor degree in environmental science/engineering from a recognised institution or equivalent tertiary study in technical area ◦ Minimum 10 years experience in environmental practice ◦ Familiarisation with relevant requirements of the OSMP and OPEP • Monitoring Provider – Field Personnel <ul style="list-style-type: none"> ◦ Familiarisation with oil sampling and recording techniques • Vessel provider <ul style="list-style-type: none"> ◦ Certificate of survey with appropriate service category • Analytical laboratory <ul style="list-style-type: none"> ◦ NATA accredited

4.3 Study O2: Water quality

An overview of the key components of Study O2 are provided below:

Component	Description
Objective	To provide a rapid assessment of the presence, type and concentrations of oil (and dispersant chemicals where relevant) in offshore and intertidal waters

Component	Description
Initiation trigger	<ul style="list-style-type: none"> The EMT Environment Leader (or delegate) has confirmed that a Level 2 or Level 3 offshore oil spill has occurred or The EMT Environment Leader (or delegate) advises that either full or partial implementation of the study is to commence
Termination trigger	<ul style="list-style-type: none"> Any related scientific monitoring studies have been initiated by the EMT Environment Leader (or delegate) and The EMT Environment Leader (or delegate) considers that continuation of monitoring under Study O2 will not result in a change to the scale or location of active response options or The EMT Environment Leader (or delegate) has advised that agreement has been reached with the Jurisdictional Authority relevant to the spill to terminate the response or The EMT Environment Leader (or delegate) has advised that continuation of monitoring under Study O2 may increase overall environmental impact
Timing	<ul style="list-style-type: none"> Where required, the Monitoring Provider/s will be activated (refer to the relevant OSMP Addendum for the petroleum activities) within 4 hours of initiation criteria being met Where required, an initial SAP to be available within 12 hours of initiation criteria being met Field surveys to commence within 24 hours of initiation criteria being met <p>Note: the initial SAP may be revised as required due to the nature of an ongoing spill event, changing operational requirements and/or results from data collected to date</p> <p>Note: timing of mobilisation and field surveys is dependent on safe operating conditions (e.g. weather, sea state, etc.) and operational access to sites</p>
Sampling Techniques	<p>Sampling techniques will vary depending on the individual event and final monitoring design. The following types of sampling may be implemented under Study O2:</p> <ul style="list-style-type: none"> Surface water sample collection <ul style="list-style-type: none"> Sampling pole with container Hose with peristaltic pump Sub-surface water sample collection <ul style="list-style-type: none"> Niskin bottle (or similar) Hose with peristaltic pump In-situ profiles <ul style="list-style-type: none"> Physio-chemical profiles Fluorometer
Standard Operating Procedures	<p>The following references are provided as guides for standard operating procedures that may be implemented under Study O2:</p> <ul style="list-style-type: none"> Oil Spill Monitoring Handbook (Hook et al 2016) <p>SOP will be confirmed by the Monitoring Provider during preparation of the SAP.</p>
Parameters	<p>Sampling parameters will vary depending on the individual event and final monitoring design. The following types of parameters may be analysed under Study O2:</p> <ul style="list-style-type: none"> Oil concentrations (e.g. TRH, BTEX, PAH, MAH) Physical parameters (e.g. temperature, salinity, DO, pH) Fluorescence Dispersant chemicals (if applied)
Guidelines	<p>The following references are provided as guidelines or thresholds that may be appropriate for comparison of results during Study O2:</p> <ul style="list-style-type: none"> Australian and New Zealand Water Quality Guidelines for Fresh and Marine Waters Quality (ANZG 2018) Oil spill modelling (NOPSEMA 2019)

Component	Description
Reporting	<ul style="list-style-type: none"> Results from in-situ sampling reported daily to the EMT Environment Leader Results from laboratory sampling reported as available to EMT Environment Leader Final report prepared within one-week of termination criteria being met and report provided to EMT Environment Leader
Key Resources	<ul style="list-style-type: none"> Monitoring Provider Vessels Analytical laboratory services
Key Competencies	<ul style="list-style-type: none"> Monitoring Provider – Study Lead <ul style="list-style-type: none"> Bachelor degree in environmental science/engineering from a recognised institution or equivalent tertiary study in technical area Minimum 10 years experience in environmental practice Familiarisation with relevant requirements of the OSMP and OPEP Monitoring Provider – Field Personnel <ul style="list-style-type: none"> Familiarisation with oil and water sampling and recording techniques Vessel provider <ul style="list-style-type: none"> Certificate of survey with appropriate service category Analytical laboratory <ul style="list-style-type: none"> NATA accredited

4.4 Study O3: Sediment quality

An overview of the key components of Study O3 are provided below:

Component	Description
Objective	To provide a rapid assessment of the presence, type and concentrations of oil (and dispersant chemicals where relevant) in offshore, intertidal and shoreline sediments
Initiation trigger	<ul style="list-style-type: none"> The EMT Environment Leader (or delegate) has confirmed that a Level 2 or Level 3 offshore oil spill has occurred and data from the OPEP Monitor and Evaluate response strategy indicates potential and/or actual sediment contact or The EMT Environment Leader (or delegate) advises that either full or partial implementation of the study is to commence
Termination trigger	<ul style="list-style-type: none"> Any related scientific monitoring studies have been initiated by the EMT Environment Leader (or delegate) and The EMT Environment Leader (or delegate) considers that continuation of monitoring under Study O3 will not result in a change to the scale or location of active response options or The EMT Environment Leader (or delegate) has advised that agreement has been reached with the Jurisdictional Authority relevant to the spill to terminate the response or The EMT Environment Leader (or delegate) has advised that continuation of monitoring under Study O3 may increase overall environmental impact
Timing	<ul style="list-style-type: none"> Where required, the Monitoring Provider/s will be activated (refer to the relevant OSMP Addendum for the petroleum activities) within 4 hours of initiation criteria being met Where required, an initial SAP to be available within 12 hours of initiation criteria being met Field surveys to commence within 24 hours of initiation criteria being met <p>Note: the initial SAP may be revised as required due to the nature of an ongoing spill event, changing operational requirements and/or results from data collected to date</p>

Component	Description
	Note: timing of mobilisation and field surveys is dependent on safe operating conditions (e.g. weather, sea state, etc.) and operational access to sites
Sampling Techniques	<p>Sampling techniques will vary depending on the individual event and final monitoring design. The following types of sampling may be implemented under Study O3:</p> <ul style="list-style-type: none"> • Subtidal sample collection <ul style="list-style-type: none"> ◦ Grab or core sampler • Intertidal/shoreline sample collection <ul style="list-style-type: none"> ◦ Cores or auger ◦ Sediment box
Standard Operating Procedures	<p>The following references are provided as guides for standard operating procedures that may be implemented under Study O3:</p> <ul style="list-style-type: none"> • Oil Spill Monitoring Handbook (Hook et al 2016) <p>SOP will be confirmed by the Monitoring Provider during preparation of the SAP.</p>
Parameters	<p>Sampling parameters will vary depending on the individual event and final monitoring design. The following types of parameters may be analysed under Study O3:</p> <ul style="list-style-type: none"> • Oil concentrations (e.g. TRH, BTEX, PAH, MAH) • Dispersant chemicals (if applied) • Total organic carbon • Physical parameters (e.g. PSD)
Guidelines	<p>The following references are provided as guidelines or thresholds that may be appropriate for comparison of results during Study O3:</p> <ul style="list-style-type: none"> • Australian and New Zealand Water Quality Guidelines for Fresh and Marine Waters Quality (ANZG 2018) • Oil spill modelling (NOPSEMA 2019)
Reporting	<ul style="list-style-type: none"> • Results from in-situ observations reported daily to the EMT Environment Leader • Results from laboratory sampling reported as available to EMT Environment Leader • Final report prepared within one-week of termination criteria being met and report provided to EMT Environment Leader
Key Resources	<ul style="list-style-type: none"> • Monitoring Provider • Vessels (island access) • Vehicles (mainland access) • Analytical laboratory services
Key Competencies	<ul style="list-style-type: none"> • Monitoring Provider – Study Lead <ul style="list-style-type: none"> ◦ Bachelor degree in environmental science/engineering from a recognised institution or equivalent tertiary study in technical area ◦ Minimum 10 years experience in environmental practice ◦ Familiarisation with relevant requirements of the OSMP and OPEP • Monitoring Provider – Field Personnel <ul style="list-style-type: none"> ◦ Familiarisation with sediment sampling and recording techniques • Vessel provider <ul style="list-style-type: none"> ◦ Certificate of survey with appropriate service category • Analytical laboratory <ul style="list-style-type: none"> ◦ NATA accredited

4.5 Study O4: Marine fauna surveillance

An overview of the key components of Study O4 are provided below:

Component	Description
Objective	To provide a rapid assessment of the presence, type and location of oiled marine fauna
Initiation trigger	<ul style="list-style-type: none"> The EMT Environment Leader (or delegate) has confirmed that a Level 2 or Level 3 offshore oil spill has occurred or The EMT Environment Leader (or delegate) advises that either full or partial implementation of the study is to commence
Termination trigger	<ul style="list-style-type: none"> Any related scientific monitoring studies have been initiated by the EMT Environment Leader (or delegate) and The EMT Environment Leader (or delegate) considers that continuation of monitoring under Study O4 will not result in a change to the scale or location of active response options or The EMT Environment Leader (or delegate) has advised that agreement has been reached with the Jurisdictional Authority relevant to the spill to terminate the response or The EMT Environment Leader (or delegate) has advised that continuation of monitoring under Study O4 may increase overall environmental impact
Timing	<ul style="list-style-type: none"> Where required, the Monitoring Provider/s will be activated (refer to the relevant OSMP Addendum for the petroleum activities) within 4 hours of initiation criteria being met Where required, an initial SAP to be available within 12 hours of initiation criteria being met Field surveys to commence within 24 hours of initiation criteria being met <p>Note: the initial SAP may be revised as required due to the nature of an ongoing spill event, changing operational requirements and/or results from data collected to date</p> <p>Note: timing of mobilisation and field surveys is dependent on safe operating conditions (e.g. weather, sea state, etc.) and operational access to sites</p>
Sampling Techniques	<p>Sampling techniques will vary depending on the individual event and final monitoring design. The following types of sampling may be implemented under Study O4:</p> <ul style="list-style-type: none"> Systematic surveillance <ul style="list-style-type: none"> Aerial observations from fixed-wing or helicopter Vessel-based observations On-ground shoreline observations Unmanned surveillance <ul style="list-style-type: none"> UAV and/or satellite Opportunistic / incidental observations Carcass collection and tissue sampling
Standard Operating Procedures	<p>The following references are provided as guides for standard operating procedures that may be implemented under Study O4:</p> <ul style="list-style-type: none"> Oil Spill Monitoring Handbook (Hook et al 2016) <p>SOP will be confirmed by the Monitoring Provider during preparation of the SAP</p>
Parameters	<p>Sampling parameters will vary depending on the individual event and final monitoring design. The following types of parameters may be recorded under Study O4 where possible:</p> <ul style="list-style-type: none"> Presence and identification (species group / species) of oiled fauna State of oiled fauna Presence and state of any carcass
Guidelines	N/A
Reporting	<ul style="list-style-type: none"> Results from in-situ observations reported daily to the EMT Environment Leader

Component	Description
	<ul style="list-style-type: none"> Final report prepared within one-week of termination criteria being met and report provided to EMT Environment Leader
Key Resources	<ul style="list-style-type: none"> Monitoring Provider Vessels Aircraft Vehicles
Key Competencies	<ul style="list-style-type: none"> Monitoring Provider – Study Lead <ul style="list-style-type: none"> Bachelor degree in environmental science/engineering from a recognised institution or equivalent tertiary study in technical area Minimum 10 years experience in environmental practice Familiarisation with relevant requirements of the OSMP and OPEP Monitoring Provider – Field Personnel <ul style="list-style-type: none"> Familiarisation with the fauna observation and recording techniques Oiled, injured, and diseased fauna handling to be undertaken by trained personnel Vessel provider <ul style="list-style-type: none"> Certificate of survey with appropriate service category Aircraft <ul style="list-style-type: none"> Current registration with CASA Analytical laboratory <ul style="list-style-type: none"> NATA accredited

4.6 Study O5: Dispersant efficacy

An overview of the key components of Study O5 are provided below:

Component	Description
Objective	Determine the effectiveness of dispersant application and reduce surface VOCs (where relevant)
Initiation trigger	<ul style="list-style-type: none"> The EMT Environment Leader (or delegate) has confirmed that a Level 2 or Level 3 offshore oil spill has occurred and the Chemical Dispersant response strategy from the OPEP has been selected for use
Termination trigger	<ul style="list-style-type: none"> Any related scientific monitoring studies have been initiated by the EMT Environment Leader (or delegate) and The EMT Environment Leader (or delegate) considers that continuation of monitoring under Study O5 will not result in a change to the scale or location of active response options or The EMT Environment Leader (or delegate) has advised that agreement has been reached with the Jurisdictional Authority relevant to the spill to terminate the response or The EMT Environment Leader (or delegate) has advised that continuation of monitoring under Study O5 may increase overall environmental impact
Timing	Study O5 is to be undertaken at the same time as the Chemical Dispersant response strategy
Sampling Techniques	<p>Sampling techniques will vary depending on the individual event and final monitoring design. The following types of sampling and surveillance may be implemented under Study O5:</p> <ul style="list-style-type: none"> Visual observations <ul style="list-style-type: none"> Aerial or vessel based Oil and water sampling

Component	Description
	<ul style="list-style-type: none"> ◦ Water sampling techniques as per Study O1 (e.g. niskin bottle, hose with peristaltic pump, etc.) ◦ Fluorometer ◦ Underwater video surveillance • Air quality monitoring <ul style="list-style-type: none"> ◦ In-situ detectors
Standard Operating Procedures	<p>The following references are provided as guides for standard operating procedures that may be implemented under Study O5:</p> <ul style="list-style-type: none"> • Oil Spill Monitoring Handbook (Hook et al 2016) • Industry Recommended Subsea Dispersant Monitoring Plan (American Petroleum Institute 2013) • Dispersant Application Monitoring Field Guide Tier I Visual Observation (OSRL 2011) • Special Monitoring of Applied Response Technologies (NOAA 2006) <p>SOP will be confirmed by the Monitoring Provider during preparation of the SAP</p>
Parameters	<p>Sampling parameters will vary depending on the individual event and final monitoring design. The following types of parameters may be analysed under Study O5:</p> <ul style="list-style-type: none"> • Oil concentrations (e.g. TRH, BTEX, PAH, MAH) • Fluorescence • VOCs and %LELs
Guidelines	<p>The following references are provided as guidelines or thresholds that may be appropriate for comparison of results during Study O5:</p> <ul style="list-style-type: none"> • Australian and New Zealand Water Quality Guidelines for Fresh and Marine Waters Quality (ANZG 2018) • Oil spill modelling (NOPSEMA 2019) • Workplace Exposure Standards for Airborne Contaminants (Safe Work Australia 2018)
Reporting	<ul style="list-style-type: none"> • Results from in-situ observations reported daily to the EMT Environment Leader • Final report prepared within one-week of termination criteria being met and report provided to EMT Environment Leader
Key Resources	<ul style="list-style-type: none"> • Monitoring Provider • Vessels • Aircraft
Key Competencies	<ul style="list-style-type: none"> • Monitoring Provider – Study Lead <ul style="list-style-type: none"> ◦ Bachelor degree in environmental science/engineering from a recognised institution or equivalent tertiary study in technical area ◦ Minimum 10 years experience in environmental practice ◦ Familiarisation with relevant requirements of the OSMP and OPEP • Monitoring Provider – Field Personnel <ul style="list-style-type: none"> ◦ Familiarisation with vessel-based and/or aerial-based oil spill monitoring ◦ Familiarisation with relevant sampling techniques (e.g. sub-surface video surveillance, use of fluorometer, water sample collection, air quality monitoring) • Vessel provider <ul style="list-style-type: none"> ◦ Certificate of survey with appropriate service category • Aircraft <ul style="list-style-type: none"> ◦ Current registration with CASA • Analytical laboratory <ul style="list-style-type: none"> ◦ NATA accredited

4.7 Study O6: Fish tainting

An overview of the key components of Study O6 are provided below:

Component	Description
Objective	To provide an assessment of the potential of fish tainting in areas of recreational and/or commercial fisheries
Initiation trigger	<ul style="list-style-type: none"> The EMT Environment Leader (or delegate) has confirmed that a Level 2 or Level 3 offshore oil spill has occurred and data from Study O2 has confirmed exposure to offshore waters above the ANZG (2018) 99% species protection levels and this exposure occurred in waters that intersect with active fisheries or The EMT Environment Leader (or delegate) advises that either full or partial implementation of the study is to commence
Termination trigger	<ul style="list-style-type: none"> Any related scientific monitoring studies have been initiated by the EMT Environment Leader (or delegate) and The EMT Environment Leader (or delegate) considers that continuation of monitoring under Study O6 will not result in a change to the scale or location of active response options or The EMT Environment Leader (or delegate) has advised that agreement has been reached with the Jurisdictional Authority relevant to the spill to terminate the response or The EMT Environment Leader (or delegate) has advised that continuation of monitoring under Study O6 may increase overall environmental impact
Timing	<ul style="list-style-type: none"> Where required, the Monitoring Provider/s will be activated (refer to the relevant OSMP Addendum for the petroleum activities) within 4 hours of initiation criteria being met Where required, an initial SAP to be available within 12 hours of initiation criteria being met Field surveys to commence within 24 hours of initiation criteria being met <p>Note: the initial SAP may be revised as required due to the nature of an ongoing spill event, changing operational requirements and/or results from data collected to date</p> <p>Note: timing of mobilisation and field surveys is dependent on safe operating conditions (e.g. weather, sea state, etc.) and operational access to sites</p>
Sampling Techniques	<p>Sampling techniques will vary depending on the individual event and final monitoring design. The following types of sampling may be implemented under Study O6:</p> <ul style="list-style-type: none"> Systematic fish sample collection <ul style="list-style-type: none"> Olfactory evaluation Tissue collection Opportunistic carcass collection and tissue sampling
Standard Operating Procedures	<p>The following references are provided as guides for standard operating procedures that may be implemented under Study O6:</p> <ul style="list-style-type: none"> Oil Spill Monitoring Handbook (Hook et al 2016) Managing Seafood Safety after an Oil Spill (Yender, Michel and Lord 2002) <p>SOP will be confirmed by the Monitoring Provider during preparation of the SAP</p>
Parameters	<p>Sampling parameters will vary depending on the individual event and final monitoring design. The following types of parameters may be analysed under Study O6:</p> <ul style="list-style-type: none"> Odour and appearance Chemical analysis of tissue samples (e.g. TRH, BTEX, PAH, MAH)
Guidelines	<p>The following references are provided as guidelines or thresholds that may be appropriate for comparison of results during Study O6:</p>

Component	Description
	<ul style="list-style-type: none"> • Australian and New Zealand Water Quality Guidelines for Fresh and Marine Waters Quality (ANZG 2018) • Australia New Zealand Food Standards Code
Reporting	<ul style="list-style-type: none"> • Results from laboratory sampling and sensory analysis reported as available to EMT Environment Leader • Final report prepared within one-week of termination criteria being met and report provided to EMT Environment Leader
Key Resources	<ul style="list-style-type: none"> • Monitoring Provider • Vessels • Analytical laboratory services
Key Competencies	<ul style="list-style-type: none"> • Monitoring Provider – Study Lead <ul style="list-style-type: none"> ◦ Bachelor degree in environmental science/engineering from a recognised institution or equivalent tertiary study in technical area ◦ Minimum 10 years experience in environmental practice ◦ Familiarisation with relevant requirements of the OSMP and OPEP • Monitoring Provider – Field Personnel <ul style="list-style-type: none"> ◦ Familiarisation with oil and water sampling and recording techniques • Monitoring Provider – Olfactory Assessment <ul style="list-style-type: none"> ◦ Trained and/or experienced olfactory analysts • Vessel provider <ul style="list-style-type: none"> ◦ Certificate of survey with appropriate service category • Analytical laboratory <ul style="list-style-type: none"> ◦ NATA accredited

5 Scientific Monitoring

5.1 Overview

The following sections outline the individual scientific monitoring studies that may be implemented in the event of a Level 2 or Level 3 oil spill to the marine or coastal environment. The tables describe the objective, initiation and termination criteria, timing, monitoring (types of sampling techniques and parameters), reporting, resources and competencies.

The studies are presented separately below; however, in practice they may be undertaken simultaneously.

Seven scientific monitoring studies have been identified:

- S1: Water quality impact assessment
- S2: Sediment quality impact assessment
- S3: Subtidal habitats impact assessment
- S4: Intertidal and coastal habitats impact assessment
- S5: Marine fauna impact assessment
- S6: Fisheries impact assessment
- S7: Heritage and socioeconomic impact assessment.

Scientific monitoring generally has objectives relating to attributing cause-effect interactions of the spill or the spill-response activities with changes to the surrounding environment. Where impacts are identified, the studies also have the objective of identifying and recommending remediation activities and monitoring for recovery. Consequently, such studies are required to account for natural or sampling variation, and study designs must be robust and produce defensible data. Scientific monitoring is typically conducted over a wider study area, extending beyond the spill footprint, and a longer time period, extending beyond the spill response.

5.1.1 General design considerations

Guidance on various experimental monitoring approaches for scientific monitoring (e.g. use of baseline data in 'before versus after' analyses, and alternative approaches such as 'control versus impact' and 'gradient approach') is provided in Appendix A. .

Termination criteria for some of the scientific monitoring modules require the use of guidelines and/or benchmark values. Where available, Australian guidelines (e.g. ANZG 2018) or regionally relevant data is used. Where these are unavailable for a selected parameter, toxicity screening benchmarks developed by the USEPA in response to the Deepwater Horizon incident (e.g. USEPA 2015), or other international guidelines (e.g. USEPA 2017) may be adopted.

5.2 Study S1: Water quality impact assessment

An overview of the key components of Study S1 are provided below:

Component	Description								
Objective	Determine the impact to, and recovery of, offshore and intertidal water quality from oil exposure and/or any impacts associated with response activities								
Initiation trigger	<ul style="list-style-type: none"> The EMT Environment Leader (or delegate) has confirmed that a Level 2 or Level 3 offshore oil spill has occurred and data from the Study O2 has confirmed exposure to offshore or intertidal waters or The EMT Environment Leader (or delegate) advises that either full or partial implementation of the study is to commence 								
Termination trigger	<ul style="list-style-type: none"> The EMT Environment Leader (or delegate) considers that: <ul style="list-style-type: none"> Hydrocarbon concentrations in offshore waters have returned to within the expected natural dynamics of baseline state and/or control sites or Hydrocarbon concentrations in offshore waters are below relevant ANZG (2018) 99% species protection levels or other applicable benchmark values and The EMT Environment Leader (or delegate) considers that: <ul style="list-style-type: none"> Relevant water quality parameter (e.g. chemicals from dispersant) concentrations in offshore waters have returned to within the expected natural dynamics of baseline state and/or control sites or Relevant water quality parameter (e.g. chemicals from dispersant) concentrations in offshore waters are below relevant ANZG (2018) 99% species protection levels or other applicable benchmark values and The EMT Environment Leader (or delegate) in conjunction with relevant government agency, considers that water quality values within protected areas (i.e. Australian Marine Parks, Ramsar wetlands or State marine protected areas) have not been impacted or have returned to within the expected natural dynamics of baseline state and Agreement has been reached with the Statutory Authority relevant to the spill to terminate the monitoring 								
Timing	<ul style="list-style-type: none"> Monitoring Provider/s will be activated (refer to the relevant OSMP Addendum for the petroleum activities) within 24 hours of initiation criteria being met <p>An initial SAP, prepared by the Monitoring Provider, to be available within 48 hours of initiation criteria being met</p> <ul style="list-style-type: none"> Consultation with relevant agencies to commence as soon as practicable after initiation criteria are met Field surveys to commence within 72 hours (3 days) of initiation criteria being met <p>Note: the initial SAP may be revised following consultation with relevant agencies and/or as required due to the nature of an ongoing spill event, changing operational requirements and/or results from data collected to date</p> <p>Note: timing of mobilisation and field surveys is dependent on safe operating conditions (e.g. weather, sea state, etc.) and operational access to sites</p>								
Monitoring Design	<p>The following are monitoring designs recommended for different spill extents/behaviour; final design will be confirmed during preparation of the SAP by the Monitoring Provider.</p> <table border="1"> <thead> <tr> <th>Spill Extent / Behaviour</th> <th>Monitoring Design</th> </tr> </thead> <tbody> <tr> <td> <ul style="list-style-type: none"> Spill plume concentrated around source, dissipating with distance </td> <td> <ul style="list-style-type: none"> Gradient approach </td> </tr> <tr> <td> <ul style="list-style-type: none"> Spill plume has dissipated away from source </td> <td> <ul style="list-style-type: none"> Gradient approach Lines of Evidence </td> </tr> <tr> <td> <ul style="list-style-type: none"> Nearshore spill or spill reaches shoreline </td> <td> <ul style="list-style-type: none"> BACI (if appropriate baseline data available) </td> </tr> </tbody> </table>	Spill Extent / Behaviour	Monitoring Design	<ul style="list-style-type: none"> Spill plume concentrated around source, dissipating with distance 	<ul style="list-style-type: none"> Gradient approach 	<ul style="list-style-type: none"> Spill plume has dissipated away from source 	<ul style="list-style-type: none"> Gradient approach Lines of Evidence 	<ul style="list-style-type: none"> Nearshore spill or spill reaches shoreline 	<ul style="list-style-type: none"> BACI (if appropriate baseline data available)
Spill Extent / Behaviour	Monitoring Design								
<ul style="list-style-type: none"> Spill plume concentrated around source, dissipating with distance 	<ul style="list-style-type: none"> Gradient approach 								
<ul style="list-style-type: none"> Spill plume has dissipated away from source 	<ul style="list-style-type: none"> Gradient approach Lines of Evidence 								
<ul style="list-style-type: none"> Nearshore spill or spill reaches shoreline 	<ul style="list-style-type: none"> BACI (if appropriate baseline data available) 								

Component	Description
	<ul style="list-style-type: none"> • IvC • Gradient approach
	<ul style="list-style-type: none"> • Spill interacts with area of biological importance (e.g. bay/shoal/island) • BACI (if appropriate baseline data available) • IvC
Scope	<p>All areas (intertidal, offshore) and water depths are included within the scope for Study S1.</p> <p>Note: where Management Plans for protected area (e.g. Australian Marine Parks, State marine protected areas, Ramsar wetlands) exist, the SAP will include consideration of any specific sampling and/or values that require monitoring</p>
Sampling Techniques	<p>Sampling techniques will vary depending on the individual event and final monitoring design. The following types of sampling may be implemented under Study S1:</p> <ul style="list-style-type: none"> • Surface water sample collection <ul style="list-style-type: none"> ◦ Sampling pole with container ◦ Hose with peristaltic pump • Sub-surface water sample collection <ul style="list-style-type: none"> ◦ Niskin bottle (or similar) ◦ Hose with peristaltic pump • In-situ profiles <ul style="list-style-type: none"> ◦ Physio-chemical profiles ◦ Fluorometer • Visual records of any damage or change due to response activities
Sampling Frequency	<ul style="list-style-type: none"> • Initial sampling frequency will be determined by during preparation of the SAP by the Monitoring Provider • Ongoing sampling frequency will be determined by the Monitoring Provider in consultation with the EMT Environment Leader following each monitoring and reporting event until termination criteria are met.
Standard Operating Procedures	<p>The following references are provided as guides for standard operating procedures that may be implemented under Study S1:</p> <ul style="list-style-type: none"> • Oil Spill Monitoring Handbook (Hook et al 2016) <p>SOP will be confirmed by the Monitoring Provider during preparation of the SAP</p>
Parameters	<p>Sampling parameters will vary depending on the individual event and final monitoring design. The following types of parameters may be analysed under Study S1:</p> <ul style="list-style-type: none"> • Oil concentrations (e.g. TRH, BTEX, PAH, MAH) • Physical parameters (e.g. temperature, salinity, DO, pH) • Fluorescence • Dispersant chemicals (if applied) and/or other water quality parameters as necessary to identify any impacts from response activities
Guidelines	<p>The following references are provided as guidelines or thresholds that may be appropriate for comparison of results during Study S1:</p> <ul style="list-style-type: none"> • Australian and New Zealand Water Quality Guidelines for Fresh and Marine Waters Quality (ANZG 2018) • Oil spill modelling (NOPSEMA 2019) • Acute and Chronic Screening Benchmarks for Water and Sediment Quality (USEPA 2015) • National Recommended Water Quality Criteria - Aquatic Life (USEPA 2017)
Reporting	<ul style="list-style-type: none"> • Data report to be provided to EMT Environment Leader following the completion of each field survey

Component	Description
	<ul style="list-style-type: none"> ◦ The data report will also contain on-going trend analysis allowing for the tracking of impacts and recovery, identification/recommendations on any remediation works or active management (including changes to existing sampling or additional sampling required) that should be considered • Final impact assessment report (addressing impacts from spill event and any relevant response activities) to be provided to EMT Environment Leader following the termination criteria being met
Key Resources	<ul style="list-style-type: none"> • Monitoring Provider • Vessels • Analytical laboratory services
Key Competencies	<ul style="list-style-type: none"> • Monitoring Provider – Study Lead <ul style="list-style-type: none"> ◦ Bachelor degree in environmental science/engineering from a recognised institution or equivalent tertiary study in technical area ◦ Minimum 10 years experience in environmental practice ◦ Familiarisation with relevant requirements of the OSMP and OPEP • Monitoring Provider – Field Personnel <ul style="list-style-type: none"> ◦ Bachelor degree in environmental science/engineering from a recognised institution or equivalent tertiary study in technical area ◦ Minimum 5 years experience in environmental practice ◦ Experienced in the relevant sampling and/or recording techniques • Monitoring Provider – Office Personnel <ul style="list-style-type: none"> ◦ Bachelor degree in environmental science/engineering from a recognised institution or equivalent tertiary study in technical area ◦ Minimum 5 years experience in environmental practice ◦ Experienced in water quality data analysis • Vessel provider <ul style="list-style-type: none"> ◦ Certificate of survey with appropriate service category • Analytical laboratory <ul style="list-style-type: none"> ◦ NATA accredited

5.3 Study S2: Sediment quality impact assessment

An overview of the key components of Study S2 are provided below:

Component	Description
Objective	Determine the impact to, and recovery of, offshore, intertidal and shoreline sediment quality from oil exposure and/or any impacts associated with response activities
Initiation trigger	<ul style="list-style-type: none"> • The EMT Environment Leader (or delegate) has confirmed that a Level 2 or Level 3 offshore oil spill has occurred and data from the Study O3 has confirmed exposure to shoreline sediments or • The EMT Environment Leader (or delegate) advises that either full or partial implementation of the study is to commence
Termination trigger	<ul style="list-style-type: none"> • The EMT Environment Leader (or delegate) considers that: <ul style="list-style-type: none"> ◦ Hydrocarbon concentrations in sediments have returned to within the expected natural dynamics of baseline state and/or control sites or

Component	Description										
	<ul style="list-style-type: none"> ◦ Hydrocarbon concentrations in sediments are below relevant ANZECC/ARMCANZ SQGV (Simpson et al. 2013) other applicable benchmark values and • The EMT Environment Leader (or delegate) considers that: <ul style="list-style-type: none"> ◦ Relevant sediment quality parameter (e.g. chemicals from dispersant) concentrations have returned to within the expected natural dynamics of baseline state and/or control sites or ◦ Relevant sediment quality parameter (e.g. chemicals from dispersant) concentrations in are below relevant ANZECC/ARMCANZ SQGV (Simpson et al. 2013) other applicable benchmark values and • The EMT Environment Leader (or delegate) in conjunction with relevant government agency, considers that sediment quality values within protected areas (i.e. Australian Marine Parks, Ramsar wetlands or State marine protected areas) have not been impacted or have returned to within the expected natural dynamics of baseline state and • Agreement has been reached with the Statutory Authority relevant to the spill to terminate the monitoring 										
Timing	<ul style="list-style-type: none"> • Monitoring Provider/s will be activated (refer to the relevant OSMP Addendum for the petroleum activities) within 24 hours of initiation criteria being met • An initial SAP, prepared by the Monitoring Provider, to be available within 48 hours of initiation criteria being met • Consultation with relevant agencies to commence as soon as practicable after initiation criteria are met • Field surveys to commence within 72 hours (3 days) of initiation criteria being met <p>Note: the initial SAP may be revised following consultation with relevant agencies and/or as required due to the nature of an ongoing spill event, changing operational requirements and/or results from data collected to date</p> <p>Note: timing of mobilisation and field surveys is dependent on safe operating conditions (e.g. weather, sea state, etc.) and operational access to sites</p>										
Monitoring Design	<p>The following are monitoring designs recommended for different spill extents/behaviour; final design will be confirmed during preparation of the SAP by the Monitoring Provider.</p> <table border="1"> <thead> <tr> <th>Spill Extent / Behaviour</th> <th>Monitoring Design</th> </tr> </thead> <tbody> <tr> <td> <ul style="list-style-type: none"> • Spill plume concentrated around source, dissipating with distance </td> <td> <ul style="list-style-type: none"> • Gradient approach </td> </tr> <tr> <td> <ul style="list-style-type: none"> • Spill plume has dissipated away from source </td> <td> <ul style="list-style-type: none"> • Gradient approach • Lines of Evidence </td> </tr> <tr> <td> <ul style="list-style-type: none"> • Nearshore spill or spill reaches shoreline </td> <td> <ul style="list-style-type: none"> • BACI (if appropriate baseline data available) • IvC • Gradient approach </td> </tr> <tr> <td> <ul style="list-style-type: none"> • Spill interacts with area of biological importance (e.g. bay/shoal/island) </td> <td> <ul style="list-style-type: none"> • BACI (if appropriate baseline data available) • IvC </td> </tr> </tbody> </table>	Spill Extent / Behaviour	Monitoring Design	<ul style="list-style-type: none"> • Spill plume concentrated around source, dissipating with distance 	<ul style="list-style-type: none"> • Gradient approach 	<ul style="list-style-type: none"> • Spill plume has dissipated away from source 	<ul style="list-style-type: none"> • Gradient approach • Lines of Evidence 	<ul style="list-style-type: none"> • Nearshore spill or spill reaches shoreline 	<ul style="list-style-type: none"> • BACI (if appropriate baseline data available) • IvC • Gradient approach 	<ul style="list-style-type: none"> • Spill interacts with area of biological importance (e.g. bay/shoal/island) 	<ul style="list-style-type: none"> • BACI (if appropriate baseline data available) • IvC
Spill Extent / Behaviour	Monitoring Design										
<ul style="list-style-type: none"> • Spill plume concentrated around source, dissipating with distance 	<ul style="list-style-type: none"> • Gradient approach 										
<ul style="list-style-type: none"> • Spill plume has dissipated away from source 	<ul style="list-style-type: none"> • Gradient approach • Lines of Evidence 										
<ul style="list-style-type: none"> • Nearshore spill or spill reaches shoreline 	<ul style="list-style-type: none"> • BACI (if appropriate baseline data available) • IvC • Gradient approach 										
<ul style="list-style-type: none"> • Spill interacts with area of biological importance (e.g. bay/shoal/island) 	<ul style="list-style-type: none"> • BACI (if appropriate baseline data available) • IvC 										
Scope	<p>All areas (shoreline, intertidal, offshore) are included within the scope for Study S2.</p> <p>Note: where Management Plans for protected area (e.g. Australian Marine Parks, State marine protected areas, Ramsar wetlands) exist, the SAP will include consideration of any specific sampling and/or values that require monitoring</p>										
Sampling Techniques	<p>Sampling techniques will vary depending on the individual event and final monitoring design. The following types of sampling may be implemented under Study S2:</p> <ul style="list-style-type: none"> • Subtidal sample collection <ul style="list-style-type: none"> ◦ Grab or core sampler • Intertidal/shoreline sample collection 										

Component	Description
	<ul style="list-style-type: none"> ◦ Cores or auger ◦ Sediment box • Visual records of any damage or change due to response activities
Sampling Frequency	<ul style="list-style-type: none"> • Initial sampling frequency will be determined by during preparation of the SAP by the Monitoring Provider • Ongoing sampling frequency will be determined by the Monitoring Provider in consultation with the EMT Environment Leader following each monitoring and reporting event until termination criteria are met.
Standard Operating Procedures	<p>The following references are provided as guides for standard operating procedures that may be implemented under Study S2:</p> <ul style="list-style-type: none"> • Oil Spill Monitoring Handbook (Hook et al 2016) <p>SOP will be confirmed by the Monitoring Provider during preparation of the SAP</p>
Parameters	<p>Sampling parameters will vary depending on the individual event and final monitoring design. The following types of parameters may be analysed under Study S2:</p> <ul style="list-style-type: none"> • Oil concentrations (e.g. TRH, BTEX, PAH, MAH) • Dispersant chemicals (if applied) • Total organic carbon • Physical parameters (e.g. PSD)
Guidelines	<p>The following references are provided as guidelines or thresholds that may be appropriate for comparison of results during Study S2:</p> <ul style="list-style-type: none"> • ANZECC/ARMCANZ SQGV (Simpson et al. 2013) • Oil spill modelling (NOPSEMA 2019) • Acute and Chronic Screening Benchmarks for Water and Sediment Quality (USEPA 2015)
Reporting	<ul style="list-style-type: none"> • Data report to be provided to EMT Environment Leader following the completion of each field survey <ul style="list-style-type: none"> ◦ The data report will also contain on-going trend analysis allowing for the tracking of impacts and recovery, identification/recommendations on any remediation works or active management (including changes to existing sampling or additional sampling required) that should be considered • Final impact assessment report (addressing impacts from spill event and any relevant response activities) to be provided to EMT Environment Leader following the termination criteria being met
Key Resources	<ul style="list-style-type: none"> • Monitoring Provider • Vessels (island access) • Vehicles (mainland access) • Analytical laboratory services
Key Competencies	<ul style="list-style-type: none"> • Monitoring Provider – Study Lead <ul style="list-style-type: none"> ◦ Bachelor degree in environmental science/engineering from a recognised institution or equivalent tertiary study in technical area ◦ Minimum 10 years experience in environmental practice ◦ Familiarisation with relevant requirements of the OSMP and OPEP • Monitoring Provider – Field Personnel <ul style="list-style-type: none"> ◦ Bachelor degree in environmental science/engineering from a recognised institution or equivalent tertiary study in technical area ◦ Minimum 5 years experience in environmental practice ◦ Experienced in the relevant sampling and/or recording techniques

Component	Description
	<ul style="list-style-type: none"> • Monitoring Provider – Office Personnel <ul style="list-style-type: none"> ◦ Bachelor degree in environmental science/engineering from a recognised institution or equivalent tertiary study in technical area ◦ Minimum 5 years experience in environmental practice ◦ Experience in sediment quality data analysis • Vessel provider <ul style="list-style-type: none"> ◦ Certificate of survey with appropriate service category • Analytical laboratory <ul style="list-style-type: none"> ◦ NATA accredited

5.4 Study S3: Subtidal habitats impact assessment

An overview of the key components of Study S3 are provided below:

Component	Description				
Objective	Determine the impact to, and recovery of, subtidal habitats from oil exposure and/or any impacts associated with response activities				
Initiation trigger	<ul style="list-style-type: none"> • The EMT Environment Leader (or delegate) has confirmed that a Level 2 or Level 3 offshore oil spill has occurred and data from the OPEP Monitor and Evaluate response strategy or Study O2 or O3 indicates potential and/or actual exposure to near-bottom waters or sediments or • The EMT Environment Leader (or delegate) advises that either full or partial implementation of the study is to commence 				
Termination trigger	<ul style="list-style-type: none"> • The EMT Environment Leader (or delegate) considers that disturbance parameters (e.g. species composition, percent cover) and health parameters (e.g. leaf condition) have returned to within the expected natural dynamics of baseline state and/or control sites and • The EMT Environment Leader (or delegate) in conjunction with relevant government agency, considers that subtidal habitat quality values within protected areas (i.e. Australian Marine Parks, Ramsar wetlands or State marine protected areas) have not been impacted or have returned to within the expected natural dynamics of baseline state and • Agreement has been reached with the Statutory Authority relevant to the spill to terminate the monitoring 				
Timing	<ul style="list-style-type: none"> • Monitoring Provider/s will be activated (refer to the relevant OSMP Addendum for the petroleum activities) within 24 hours of initiation criteria being met • An initial SAP, prepared by the Monitoring Provider, to be available within 72 hours of the initiation criteria being met • Consultation with relevant agencies to commence as soon as practicable after initiation criteria are met • Field surveys to commence within 120 hours (5 days) of initiation criteria being met <p>Note: the initial SAP may be revised following consultation with relevant agencies and/or as required due to the nature of an ongoing spill event, changing operational requirements and/or results from data collected to date</p> <p>Note: timing of mobilisation and field surveys is dependent on safe operating conditions (e.g. weather, sea state, etc.) and operational access to sites</p>				
Monitoring Design	The following are monitoring designs recommended for different spill extents/behaviour; final design will be confirmed during preparation of the SAP by the Monitoring Provider.				
	<table border="1"> <thead> <tr> <th>Spill Extent / Behaviour</th> <th>Monitoring Design</th> </tr> </thead> <tbody> <tr> <td></td> <td></td> </tr> </tbody> </table>	Spill Extent / Behaviour	Monitoring Design		
Spill Extent / Behaviour	Monitoring Design				

Component	Description
	<ul style="list-style-type: none"> • Spill plume concentrated around source, dissipating with distance • Gradient approach <hr/> <ul style="list-style-type: none"> • Spill plume has dissipated away from source • Gradient approach • Lines of Evidence <hr/> <ul style="list-style-type: none"> • Nearshore spill or spill reaches shoreline • BACI (if appropriate baseline data available) • IvC • Gradient approach • Lines of Evidence <hr/> <ul style="list-style-type: none"> • Spill interacts with area of biological importance (e.g. bay/shoal/island) • BACI (if appropriate baseline data available) • IvC • Lines of Evidence
Scope	<p>Soft and hard substrate subtidal benthic habitats and their associated organisms covered by Study S3 include:</p> <ul style="list-style-type: none"> • Hard (scleractinian) corals, turf and coralline algae • Sponges and other filter feeders • Macroalgae (including turf and encrusting coralline algae) and seagrasses; • Kelp • Large and conspicuous (i.e. epifaunal) motile invertebrates (e.g. crustaceans and molluscs) <p>Note: where Management Plans for protected area (e.g. Australian Marine Parks, State marine protected areas, Ramsar wetlands) exist, the SAP will include consideration of any specific sampling and/or values that require monitoring</p>
Sampling Techniques	<p>Sampling techniques will vary depending on the individual event and final monitoring design. The following types of sampling may be implemented under Study S3:</p> <ul style="list-style-type: none"> • Dive / towed video / drop camera / ROV surveys <ul style="list-style-type: none"> ◦ Transects ◦ Quadrats ◦ Sediment grab (for soft-bottom habitat) • Remote sensing • Biological sample collection • Records of any damage or change due to response activities
Sampling Frequency	<ul style="list-style-type: none"> • Survey timing should coincide with that appropriate for the habitat and/or community of interest • Initial sampling frequency will be determined by during preparation of the SAP by the Monitoring Provider • Ongoing sampling frequency will be determined by the Monitoring Provider in consultation with the EMT Environment Leader following each monitoring and reporting event until termination criteria are met
Standard Operating Procedures	<p>The following references are provided as guides for standard operating procedures that may be implemented under Study S3:</p> <ul style="list-style-type: none"> • Parks Victoria Standard Operating Procedure for Biological Monitoring of Subtidal Reefs (Edmunds and Hart 2005) • Oil Spill Monitoring Handbook (Hook et al 2016) <p>SOP will be confirmed by the Monitoring Provider during preparation of the SAP</p>
Parameters	<p>Sampling parameters will vary depending on the individual event and final monitoring design. The following types of parameters may be analysed under Study S3:</p> <ul style="list-style-type: none"> • Habitat/substrate type

Component	Description
	<ul style="list-style-type: none"> • Abundance and percent cover • Diversity • Distribution • State (e.g. evidence of stress, necrosis, leaf condition etc.) • Chemical analysis of tissue samples (e.g. TRH, BTEX, PAH, MAH)
Guidelines	<p>The following references are provided as guidelines or thresholds that may be appropriate for comparison of results during Study S3:</p> <ul style="list-style-type: none"> • Australian and New Zealand Water Quality Guidelines for Fresh and Marine Waters Quality (ANZG 2018)
Reporting	<ul style="list-style-type: none"> • Data report to be provided to EMT Environment Leader following the completion of each field survey <ul style="list-style-type: none"> ◦ The data report will also contain on-going trend analysis allowing for the tracking of impacts and recovery, identification/recommendations on any remediation works or active management (including changes to existing sampling or additional sampling required) that should be considered • Final impact assessment report (addressing impacts from spill event and any relevant response activities) to be provided to EMT Environment Leader following the termination criteria being met
Key Resources	<ul style="list-style-type: none"> • Monitoring Provider • Vessels • ROV
Key Competencies	<ul style="list-style-type: none"> • Monitoring Provider – Study Lead <ul style="list-style-type: none"> ◦ Bachelor degree in environmental science/engineering from a recognised institution or equivalent tertiary study in technical area ◦ Minimum 10 years experience in environmental practice ◦ Familiarisation with relevant requirements of the OSMP and OPEP • Monitoring Provider – Field Personnel <ul style="list-style-type: none"> ◦ Bachelor degree in environmental science/engineering from a recognised institution or equivalent tertiary study in technical area ◦ Minimum 5 years experience in environmental practice ◦ Commercial dive qualifications ◦ Experienced in the relevant sampling and/or recording techniques ◦ Experienced in commercial ROV operations • Monitoring Provider – Office Personnel <ul style="list-style-type: none"> ◦ Bachelor degree in environmental science/engineering from a recognised institution or equivalent tertiary study in technical area ◦ Minimum 5 years experience in environmental practice ◦ Experience in identification, analysis and interpretation of benthic habitat data • Vessel provider <ul style="list-style-type: none"> ◦ Certificate of survey with appropriate service category ◦ Suitable for commercial diving operations

5.5 Study S4: Intertidal and coastal habitats impact assessment

An overview of the key components of Study S4 are provided below:

Component	Description										
Objective	Determine the impact to, and recovery of, intertidal and coastal habitats from oil exposure and/or any impacts associated with response activities										
Initiation trigger	<ul style="list-style-type: none"> The EMT Environment Leader (or delegate) has confirmed that a Level 2 or Level 3 offshore oil spill has occurred and data from the OPEP Monitor and Evaluate response strategy or Study O2 or O3 indicates potential and/or actual exposure to near-bottom waters or sediments or The EMT Environment Leader (or delegate) advises that either full or partial implementation of the study is to commence 										
Termination trigger	<ul style="list-style-type: none"> The EMT Environment Leader (or delegate) considers that disturbance parameters (e.g. species composition, percent cover) and health parameters (e.g. leaf condition) have returned to within the expected natural dynamics of baseline state and/or control sites and The EMT Environment Leader (or delegate) in conjunction with relevant government agency, considers that intertidal habitat quality values within protected areas (i.e. Ramsar wetlands or State marine protected areas) have not been impacted or have returned to within the expected natural dynamics of baseline state and Agreement has been reached with the Statutory Authority relevant to the spill to terminate the monitoring 										
Timing	<ul style="list-style-type: none"> Monitoring Provider/s will be activated (refer to the relevant OSMP Addendum for the petroleum activities) within 24 hours of initiation criteria being met An initial SAP, prepared by the Monitoring Provider, to be available within 72 hours of the initiation criteria being met Consultation with relevant agencies to commence as soon as practicable after initiation criteria are met Field surveys to commence within 120 hours (5 days) of initiation criteria being met <p>Note: the initial SAP may be revised following consultation with relevant agencies and/or as required due to the nature of an ongoing spill event, changing operational requirements and/or results from data collected to date</p> <p>Note: timing of mobilisation and field surveys is dependent on safe operating conditions (e.g. weather, sea state, etc.) and operational access to sites</p>										
Monitoring Design	<p>The following are monitoring designs recommended for different spill extents/behaviour; final design will be confirmed during preparation of the SAP by the Monitoring Provider.</p> <table border="1"> <thead> <tr> <th>Spill Extent / Behaviour</th> <th>Monitoring Design</th> </tr> </thead> <tbody> <tr> <td> <ul style="list-style-type: none"> Spill plume concentrated around source, dissipating with distance </td> <td> <ul style="list-style-type: none"> Gradient approach </td> </tr> <tr> <td> <ul style="list-style-type: none"> Spill plume has dissipated away from source </td> <td> <ul style="list-style-type: none"> Gradient approach Lines of Evidence </td> </tr> <tr> <td> <ul style="list-style-type: none"> Nearshore spill or spill reaches shoreline </td> <td> <ul style="list-style-type: none"> BACI (if appropriate baseline data available) IvC Gradient approach Lines of Evidence </td> </tr> <tr> <td> <ul style="list-style-type: none"> Spill interacts with area of biological importance (e.g. bay/shoal/island) </td> <td> <ul style="list-style-type: none"> BACI (if appropriate baseline data available) IvC Lines of Evidence </td> </tr> </tbody> </table>	Spill Extent / Behaviour	Monitoring Design	<ul style="list-style-type: none"> Spill plume concentrated around source, dissipating with distance 	<ul style="list-style-type: none"> Gradient approach 	<ul style="list-style-type: none"> Spill plume has dissipated away from source 	<ul style="list-style-type: none"> Gradient approach Lines of Evidence 	<ul style="list-style-type: none"> Nearshore spill or spill reaches shoreline 	<ul style="list-style-type: none"> BACI (if appropriate baseline data available) IvC Gradient approach Lines of Evidence 	<ul style="list-style-type: none"> Spill interacts with area of biological importance (e.g. bay/shoal/island) 	<ul style="list-style-type: none"> BACI (if appropriate baseline data available) IvC Lines of Evidence
Spill Extent / Behaviour	Monitoring Design										
<ul style="list-style-type: none"> Spill plume concentrated around source, dissipating with distance 	<ul style="list-style-type: none"> Gradient approach 										
<ul style="list-style-type: none"> Spill plume has dissipated away from source 	<ul style="list-style-type: none"> Gradient approach Lines of Evidence 										
<ul style="list-style-type: none"> Nearshore spill or spill reaches shoreline 	<ul style="list-style-type: none"> BACI (if appropriate baseline data available) IvC Gradient approach Lines of Evidence 										
<ul style="list-style-type: none"> Spill interacts with area of biological importance (e.g. bay/shoal/island) 	<ul style="list-style-type: none"> BACI (if appropriate baseline data available) IvC Lines of Evidence 										

Component	Description
Scope	<p>Intertidal and coastal habitats covered by Study S4 include:</p> <ul style="list-style-type: none"> • Mangroves • Saltmarsh • Macroalgae and seagrass (only those occurring in the intertidal zone) • Invertebrates (molluscs, crustaceans) and other rocky, muddy and sandy shore biota occurring in the intertidal zone • Shoreline/coastal areas <p>Note: where Management Plans for protected area (e.g. Ramsar wetlands) exist, the SAP will include consideration of any specific sampling and/or values that require monitoring</p>
Sampling Techniques	<p>Sampling techniques will vary depending on the individual event and final monitoring design. The following types of sampling may be implemented under Study S4:</p> <ul style="list-style-type: none"> • Ground / dive / snorkel / drop camera <ul style="list-style-type: none"> ◦ Transects ◦ Quadrats ◦ Sediment grab (for soft-bottom habitat) • Remote sensing • Biological sample collection • Records of any damage or change due to response activities
Sampling Frequency	<ul style="list-style-type: none"> • Survey timing should coincide with that appropriate for the habitat and/or community of interest • Initial sampling frequency will be determined by during preparation of the SAP by the Monitoring Provider • Ongoing sampling frequency will be determined by the Monitoring Provider in consultation with the EMT Environment Leader following each monitoring and reporting event until termination criteria are met
Standard Operating Procedures	<p>The following references are provided as guides for standard operating procedures that may be implemented under Study S4:</p> <ul style="list-style-type: none"> • Parks Victoria Standard Operating Procedure for Biological Monitoring of Intertidal Reefs (Hart and Edmunds 2005) • Oil Spill Monitoring Handbook (Hook et al 2016) <p>SOP will be confirmed by the Monitoring Provider during preparation of the SAP</p>
Parameters	<p>Sampling parameters will vary depending on the individual event and final monitoring design. The following types of parameters may be analysed under Study S4:</p> <ul style="list-style-type: none"> • Habitat/substrate type • Abundance and percent cover • Diversity • Distribution • State (e.g. evidence of stress, necrosis, leaf condition etc.) • Chemical analysis of tissue samples (e.g. TRH, BTEX, PAH, MAH) • Condition and quality of coastal environment (e.g. evidence of disturbance to sediment profile or environmental values from response [shoreline clean-up, oiled wildlife] activities)
Guidelines	<p>The following references are provided as guidelines or thresholds that may be appropriate for comparison of results during Study S4:</p> <ul style="list-style-type: none"> • Australian and New Zealand Water Quality Guidelines for Fresh and Marine Waters Quality (ANZG 2018)
Reporting	<ul style="list-style-type: none"> • Data report to be provided to EMT Environment Leader following the completion of each field survey

Component	Description
	<ul style="list-style-type: none"> ◦ The data report will also contain on-going trend analysis allowing for the tracking of impacts and recovery, identification/recommendations on any remediation works or active management (including changes to existing sampling or additional sampling required) that should be considered • Final impact assessment report (addressing impacts from spill event and any relevant response activities) to be provided to EMT Environment Leader following the termination criteria being met
Key Resources	<ul style="list-style-type: none"> • Monitoring Provider • Vessels (island access) • Vehicles (mainland access)
Key Competencies	<ul style="list-style-type: none"> • Monitoring Provider – Study Lead <ul style="list-style-type: none"> ◦ Bachelor degree in environmental science/engineering from a recognised institution or equivalent tertiary study in technical area ◦ Minimum 10 years experience in environmental practice ◦ Familiarisation with relevant requirements of the OSMP and OPEP • Monitoring Provider – Field Personnel <ul style="list-style-type: none"> ◦ Bachelor degree in environmental science/engineering from a recognised institution or equivalent tertiary study in technical area ◦ Minimum 5 years experience in environmental practice ◦ Experienced in the relevant sampling and/or recording techniques • Monitoring Provider – Office Personnel <ul style="list-style-type: none"> ◦ Bachelor degree in environmental science/engineering from a recognised institution or equivalent tertiary study in technical area ◦ Minimum 5 years experience in environmental practice ◦ Experience in identification, analysis and interpretation of benthic habitat data • Vessel provider <ul style="list-style-type: none"> ◦ Certificate of survey with appropriate service category

5.6 Study S5: Marine fauna impact assessment

An overview of the key components of Study S5 are provided below:

Component	Description
Objective	Determine the impact to, and recovery of, marine fauna from oil exposure and/or any impacts associated with response activities
Initiation trigger	<ul style="list-style-type: none"> • The EMT Environment Leader (or delegate) has confirmed that a Level 2 or Level 3 offshore oil spill has occurred and data from the Study O4 has confirmed exposure to marine fauna or • The EMT Environment Leader (or delegate) advises that either full or partial implementation of the study is to commence
Termination trigger	<ul style="list-style-type: none"> • The EMT Environment Leader (or delegate) considers that disturbance parameters (e.g. population size, breeding success) have returned to within the expected natural dynamics of baseline state and/or control sites and • The EMT Environment Leader (or delegate) in conjunction with relevant government agency, considers that protected marine fauna (i.e. threatened or migratory species) have not been impacted or have returned to within the expected natural dynamics of baseline state (including any assessment against management requirements in Conservation Advices and/or Recovery Plans) and

Component	Description						
	<ul style="list-style-type: none"> Agreement has been reached with the Statutory Authority relevant to the spill to terminate the monitoring 						
Timing	<ul style="list-style-type: none"> Monitoring Provider/s will be activated (refer to the relevant OSMP Addendum for the petroleum activities) within 24 hours of initiation criteria being met An initial SAP, prepared by the Monitoring Provider, to be available within 72 hours of initiation criteria being met Consultation with relevant agencies to commence as soon as practicable after initiation criteria are met Field surveys to commence within 96 hours (4 days) of initiation criteria being met <p>Note: the initial SAP may be revised following consultation with relevant agencies and/or as required due to the nature of an ongoing spill event, changing operational requirements and/or results from data collected to date</p> <p>Note: timing of mobilisation and field surveys is dependent on safe operating conditions (e.g. weather, sea state, etc.) and operational access to sites</p>						
Monitoring Design	<p>The following are monitoring designs recommended for different spill extents/behaviour; final design will be confirmed during preparation of the SAP by the Monitoring Provider.</p> <table border="1"> <thead> <tr> <th>Spill Extent / Behaviour</th> <th>Monitoring Design</th> </tr> </thead> <tbody> <tr> <td> <ul style="list-style-type: none"> Spill reaches shoreline with known roosting/breeding/nesting/haul-out habitat </td> <td> <ul style="list-style-type: none"> BACI (if appropriate baseline data available) Control chart (if appropriate baseline data available) IvC Gradient approach Lines of Evidence </td> </tr> <tr> <td> <ul style="list-style-type: none"> Spill intersects with area of biological importance (e.g. foraging areas) </td> <td> <ul style="list-style-type: none"> BACI (if appropriate baseline data available) Control chart (if appropriate baseline data available) IvC Gradient approach Lines of Evidence </td> </tr> </tbody> </table>	Spill Extent / Behaviour	Monitoring Design	<ul style="list-style-type: none"> Spill reaches shoreline with known roosting/breeding/nesting/haul-out habitat 	<ul style="list-style-type: none"> BACI (if appropriate baseline data available) Control chart (if appropriate baseline data available) IvC Gradient approach Lines of Evidence 	<ul style="list-style-type: none"> Spill intersects with area of biological importance (e.g. foraging areas) 	<ul style="list-style-type: none"> BACI (if appropriate baseline data available) Control chart (if appropriate baseline data available) IvC Gradient approach Lines of Evidence
Spill Extent / Behaviour	Monitoring Design						
<ul style="list-style-type: none"> Spill reaches shoreline with known roosting/breeding/nesting/haul-out habitat 	<ul style="list-style-type: none"> BACI (if appropriate baseline data available) Control chart (if appropriate baseline data available) IvC Gradient approach Lines of Evidence 						
<ul style="list-style-type: none"> Spill intersects with area of biological importance (e.g. foraging areas) 	<ul style="list-style-type: none"> BACI (if appropriate baseline data available) Control chart (if appropriate baseline data available) IvC Gradient approach Lines of Evidence 						
Scope	<p>Marine fauna covered by Study S5 include:</p> <ul style="list-style-type: none"> Seabirds and shorebirds Marine megafauna (pinnipeds, reptiles, sharks, cetaceans) <p>Note: where Conservation Advice and/or Recovery Plans exist for protected marine fauna, the SAP will include consideration of any specific sampling and/or values that require monitoring</p>						
Sampling Technique	<p>Sampling techniques will vary depending on the individual event and final monitoring design. The following types of sampling may be implemented under Study S5:</p> <ul style="list-style-type: none"> Systematic surveillance (e.g. transects) <ul style="list-style-type: none"> Aerial observations from fixed-wing or helicopter Vessel-based observations On-ground shoreline observations Unmanned surveillance <ul style="list-style-type: none"> UAV and/or satellite Tissue sample collection and analysis Opportunistic / incidental observations Carcass collection and tissue sampling Records of any damage or change due to response activities 						

Component	Description
Sampling Frequency	<ul style="list-style-type: none"> Survey timing should coincide with that appropriate for the marine fauna of interest Initial sampling frequency will be determined by during preparation of the SAP by the Monitoring Provider Ongoing sampling frequency will be determined by the Monitoring Provider in consultation with the EMT Environment Leader following each monitoring and reporting event until termination criteria are met
Standard Operating Procedures	<p>The following references are provided as guides for standard operating procedures that may be implemented under Study S5:</p> <ul style="list-style-type: none"> Oil Spill Monitoring Handbook (Hook et al 2016) <p>SOP will be confirmed by the Monitoring Provider during preparation of the SAP</p>
Parameters	<p>Sampling parameters will vary depending on the individual event and final monitoring design. The following types of parameters may be analysed under Study S5:</p> <ul style="list-style-type: none"> Nest/burrow presence Abundance (adults, juveniles, fledging/hatchling etc) Density Distribution State (e.g. evidence of stress, oil cover, injured etc.) Chemical analysis of tissue samples (e.g. TRH, BTEX, PAH, MAH) Presence and state of any carcass
Guidelines	<p>The following references are provided as guidelines or thresholds that may be appropriate for comparison of results during Study S4:</p> <ul style="list-style-type: none"> Australian and New Zealand Water Quality Guidelines for Fresh and Marine Waters Quality (ANZG 2018)
Reporting	<ul style="list-style-type: none"> Data report to be provided to EMT Environment Leader following the completion of each field survey <ul style="list-style-type: none"> The data report will also contain on-going trend analysis allowing for the tracking of impacts and recovery, identification/recommendations on any remediation works or active management (including changes to existing sampling or additional sampling required) that should be considered Final impact assessment report (addressing impacts from spill event and any relevant response activities) to be provided to EMT Environment Leader following the termination criteria being met
Key Resources	<ul style="list-style-type: none"> Monitoring Provider Vessels Aircraft Vehicles Analytical laboratory services
Key Competencies	<ul style="list-style-type: none"> Monitoring Provider – Study Lead <ul style="list-style-type: none"> Bachelor degree in environmental science/engineering from a recognised institution or equivalent tertiary study in technical area Minimum 10 years experience in environmental practice Familiarisation with relevant requirements of the OSMP and OPEP Monitoring Provider – Field Personnel <ul style="list-style-type: none"> Bachelor degree in environmental science/engineering from a recognised institution or equivalent tertiary study in technical area Minimum 5 years experience in environmental practice Experienced in the relevant sampling and/or recording techniques

Component	Description
	<ul style="list-style-type: none"> ◦ Oiled, injured, and diseased fauna handling to be undertaken by trained personnel • Monitoring Provider – Office Personnel <ul style="list-style-type: none"> ◦ Bachelor degree in environmental science/engineering from a recognised institution or equivalent tertiary study in technical area ◦ Minimum 5 years experience in environmental practice ◦ Experience in identification, analysis and interpretation of biota data • Vessel provider <ul style="list-style-type: none"> ◦ Certificate of survey with appropriate service category • Analytical laboratory <ul style="list-style-type: none"> ◦ NATA accredited

5.7 Study S6: Fisheries impact assessment

An overview of the key components of Study S6 are provided below:

Component	Description				
Objective	Determine the presence of, and recovery from, oil taint in commercially or recreationally important fish species and/or any impacts associated with response activities				
Initiation trigger	<ul style="list-style-type: none"> • The EMT Environment Leader (or delegate) has confirmed that a Level 2 or Level 3 offshore oil spill has occurred and data from Study O6 has confirmed the presence of fishing tainting or • Allegations of damage are received from commercial fisheries or government agencies or • The EMT Environment Leader (or delegate) advises that either full or partial implementation of the study is to commence 				
Termination trigger	<ul style="list-style-type: none"> • The EMT Environment Leader (or delegate) considers that: <ul style="list-style-type: none"> ◦ Fish or shellfish show no presence of tissue taint or ◦ PAH levels in fish and shellfish tissue have returned to within the expected natural dynamics of baseline state and/or control sites or ◦ PAH levels in fish and shellfish tissue are at or below regulatory levels of concern and • Agreement has been reached with the Statutory Authority relevant to the spill to terminate the monitoring 				
Timing	<ul style="list-style-type: none"> • Monitoring Provider/s will be activated (refer to the relevant OSMP Addendum for the petroleum activities) within 24 hours of initiation criteria being met • An initial SAP, prepared by the Monitoring Provider, to be available within 72 hours of initiation criteria being met • Consultation with relevant agencies to commence as soon as practicable after initiation criteria are met • Field surveys to commence within 120 hours (5 days) of initiation criteria being met <p>Note: the initial SAP may be revised following consultation with relevant agencies and/or as required due to the nature of an ongoing spill event, changing operational requirements and/or results from data collected to date</p> <p>Note: timing of mobilisation and field surveys is dependent on safe operating conditions (e.g. weather, sea state, etc.) and operational access to sites</p>				
Monitoring Design	<p>The following are monitoring designs recommended for different spill extents/behaviour; final design will be confirmed during preparation of the SAP by the Monitoring Provider.</p> <table border="1"> <thead> <tr> <th>Spill Extent / Behaviour</th> <th>Monitoring Design</th> </tr> </thead> <tbody> <tr> <td></td> <td></td> </tr> </tbody> </table>	Spill Extent / Behaviour	Monitoring Design		
Spill Extent / Behaviour	Monitoring Design				

Component	Description
	<ul style="list-style-type: none"> • Offshore spill <ul style="list-style-type: none"> • Gradient approach • Lines of Evidence • Nearshore spill or spill reaches nearshore areas <ul style="list-style-type: none"> • BACI (if appropriate baseline data available) • IvC • Gradient approach • Lines of Evidence
Sampling Techniques	<p>Sampling techniques will vary depending on the individual event and final monitoring design. The following types of sampling may be implemented under Study S6:</p> <ul style="list-style-type: none"> • Systematic fish sample collection <ul style="list-style-type: none"> ◦ Olfactory evaluation ◦ Tissue collection • Opportunistic carcass collection and tissue sampling • Records of any damage or change due to response activities
Sampling Frequency	<ul style="list-style-type: none"> • Survey timing should coincide with that appropriate for the fish species of interest • Initial sampling frequency will be determined by during preparation of the SAP by the Monitoring Provider • Ongoing sampling frequency will be determined by the Monitoring Provider in consultation with the EMT Environment Leader following each monitoring and reporting event until termination criteria are met
Standard Operating Procedures	<p>The following references are provided as guides for standard operating procedures that may be implemented under Study S5:</p> <ul style="list-style-type: none"> • Oil Spill Monitoring Handbook (Hook et al 2016) • Managing Seafood Safety after an Oil Spill (Yender, Michel and Lord 2002) <p>SOP will be confirmed by the Monitoring Provider during preparation of the SAP</p>
Parameters	<p>Sampling parameters will vary depending on the individual event and final monitoring design. The following types of parameters may be analysed under Study S6:</p> <ul style="list-style-type: none"> • Odour and appearance • Chemical analysis of tissue samples (e.g. TRH, BTEX, PAH, MAH) • Fish health indicators and biomarkers (e.g. liver enzymes, PAH metabolites)
Guidelines	<p>The following references are provided as guidelines or thresholds that may be appropriate for comparison of results during Study O1:</p> <ul style="list-style-type: none"> • Australian and New Zealand Water Quality Guidelines for Fresh and Marine Waters Quality (ANZG 2018) • Australia New Zealand Food Standards Code
Reporting	<ul style="list-style-type: none"> • Data report to be provided to EMT Environment Leader following the completion of each field survey <ul style="list-style-type: none"> ◦ The data report will also contain on-going trend analysis allowing for the tracking of impacts and recovery, identification/recommendations on any remediation works or active management (including changes to existing sampling or additional sampling required) that should be considered • Final impact assessment report (addressing impacts from spill event and any relevant response activities) to be provided to EMT Environment Leader following the termination criteria being met
Key Resources	<ul style="list-style-type: none"> • Monitoring Provider • Olfactory Analysis Panel • Vessels • Analytical laboratory services

Component	Description
Key Competencies	<ul style="list-style-type: none"> • Monitoring Provider – Study Lead <ul style="list-style-type: none"> ◦ Bachelor degree in environmental science/engineering from a recognised institution or equivalent tertiary study in technical area ◦ Minimum 10 years experience in environmental practice ◦ Familiarisation with relevant requirements of the OSMP and OPEP • Monitoring Provider – Field Personnel <ul style="list-style-type: none"> ◦ Bachelor degree in environmental science/engineering from a recognised institution or equivalent tertiary study in technical area ◦ Minimum 5 years experience in environmental practice ◦ Experienced in the relevant sampling and/or recording techniques • Monitoring Provider – Office Personnel <ul style="list-style-type: none"> ◦ Bachelor degree in environmental science/engineering from a recognised institution or equivalent tertiary study in technical area ◦ Minimum 5 years experience in environmental practice ◦ Experience in analysis and interpretation of biota data • Monitoring Provider – Olfactory Assessment Panel <ul style="list-style-type: none"> ◦ Trained and/or experienced olfactory analysts • Vessel provider <ul style="list-style-type: none"> ◦ Certificate of survey with appropriate service category • Analytical laboratory <ul style="list-style-type: none"> ◦ NATA accredited

5.8 Study S7: Heritage and socioeconomic impact assessment

An overview of the key components of Study S7 are provided below:

Component	Description
Objective	Determine the impact to, and recovery of, heritage and socioeconomic features from oil exposure and/or any impacts associated with response activities
Initiation trigger	<ul style="list-style-type: none"> • The EMT Environment Leader (or delegate) has confirmed that a Level 2 or Level 3 offshore oil spill has occurred and data from the OPEP Monitor and Evaluate response strategy or Study O2 or O3 indicates potential and/or actual exposure to known areas of heritage or socioeconomic features or • Allegations of damage are received from other users (e.g. tourism operators, heritage groups) s or government agencies or • The EMT Environment Leader (or delegate) advises that either full or partial implementation of the study is to commence
Termination trigger	<ul style="list-style-type: none"> • The EMT Environment Leader (or delegate) considers that disturbance parameters (e.g. hydrocarbon visibility and concentration, condition/quality, area usage levels) have returned to within the expected natural dynamics of baseline state and/or control sites and • The EMT Environment Leader (or delegate) in conjunction with relevant government agency, considers that heritage and/or socioeconomic features have not been impacted or have returned to within the expected natural dynamics of baseline state and • Agreement has been reached with the Statutory Authority relevant to the spill to terminate the monitoring

Component	Description						
Timing	<ul style="list-style-type: none"> Monitoring Provider/s will be activated (refer to the relevant OSMP Addendum for the petroleum activities) within 24 hours of initiation criteria being met An initial SAP, prepared by the Monitoring Provider, to be available within 72 hours of initiation criteria being met Consultation with relevant agencies to commence as soon as practicable after initiation criteria are met Desktop and/or field surveys to commence within 96 hours (4 days) of initiation criteria being met <p>Note: the initial SAP may be revised following consultation with relevant agencies and/or as required due to the nature of an ongoing spill event, changing operational requirements and/or results from data collected to date</p> <p>Note: timing of mobilisation and field surveys is dependent on safe operating conditions (e.g. weather, sea state, etc.) and operational access to sites</p>						
Monitoring Design	<p>The following are monitoring designs recommended for different spill extents/behaviour; final design will be confirmed during preparation of the SAP by the Monitoring Provider.</p> <table border="1"> <thead> <tr> <th>Spill Extent / Behaviour</th> <th>Monitoring Design</th> </tr> </thead> <tbody> <tr> <td> <ul style="list-style-type: none"> Offshore spill </td> <td> <ul style="list-style-type: none"> Gradient approach Lines of Evidence </td> </tr> <tr> <td> <ul style="list-style-type: none"> Nearshore spill or spill reaches nearshore areas </td> <td> <ul style="list-style-type: none"> IvC Gradient approach Lines of Evidence </td> </tr> </tbody> </table>	Spill Extent / Behaviour	Monitoring Design	<ul style="list-style-type: none"> Offshore spill 	<ul style="list-style-type: none"> Gradient approach Lines of Evidence 	<ul style="list-style-type: none"> Nearshore spill or spill reaches nearshore areas 	<ul style="list-style-type: none"> IvC Gradient approach Lines of Evidence
Spill Extent / Behaviour	Monitoring Design						
<ul style="list-style-type: none"> Offshore spill 	<ul style="list-style-type: none"> Gradient approach Lines of Evidence 						
<ul style="list-style-type: none"> Nearshore spill or spill reaches nearshore areas 	<ul style="list-style-type: none"> IvC Gradient approach Lines of Evidence 						
Scope	<p>Heritage and socioeconomic features covered by Study S7 include:</p> <ul style="list-style-type: none"> Cultural and heritage features (e.g. World, Commonwealth or National heritage listed places) Indigenous heritage features (e.g. Indigenous Protected Areas, areas with artefacts or other cultural sensitivity) Underwater cultural heritage features (e.g. shipwrecks, sunken artefacts) Socioeconomic features (e.g. tourism and recreational activities, commercial shipping, other marine users) <p>Note: commercial fisheries are included within Study S6.</p>						
Sampling Techniques	<p>Sampling techniques will vary depending on the individual event and final monitoring design. The following types of sampling may be implemented under Study S7:</p> <ul style="list-style-type: none"> Desktop assessment <ul style="list-style-type: none"> Identification of heritage and/or socioeconomic features at risk based on direct or indirect change to ambient environmental conditions (e.g. water and sediment quality) or values Notifications to any relevant government agencies (e.g. Heritage Victoria, Department of the Environment and Energy etc.) as required Assessment of each affected feature and development of appropriate monitoring and management recommendations and develop appropriate Field data collection <ul style="list-style-type: none"> Visual inspection and records of any changes to condition, exposure to oil, changes in behaviour or use etc. Systematic surveillance (e.g. transects) using aerial, vessel or on-ground observations as appropriate Records of any damage or change due to response activities 						
Sampling Frequency	<ul style="list-style-type: none"> Initial sampling frequency will be determined by during preparation of the SAP by the Monitoring Provider 						

Component	Description
	<ul style="list-style-type: none"> Ongoing sampling frequency will be determined by the Monitoring Provider in consultation with the EMT Environment Leader following each monitoring and reporting event until termination criteria are met
Standard Operating Procedures	SOP for heritage and socioeconomic studies will be developed in consultation with the appropriate government agency with responsibility for protection of features
Parameters	<p>Sampling parameters will vary depending on the individual event and final monitoring design. The following types of parameters may be analysed under Study S6:</p> <ul style="list-style-type: none"> Visual appearance Condition (e.g. evidence of oil cover, damage etc.) Use of parameters from other studies as required (e.g. water and sediment quality monitoring)
Guidelines	N/A
Reporting	<ul style="list-style-type: none"> Data report to be provided to EMT Environment Leader following the completion of each desktop or field survey <ul style="list-style-type: none"> The data report will also contain on-going trend analysis allowing for the tracking of impacts and recovery, identification/recommendations on any remediation works or active management (including changes to existing sampling or additional sampling required) that should be considered Final impact assessment report (addressing impacts from spill event and any relevant response activities) to be provided to EMT Environment Leader following the termination criteria being met
Key Resources	<ul style="list-style-type: none"> Monitoring Provider Vessels
Key Competencies	<ul style="list-style-type: none"> Monitoring Provider – Study Lead <ul style="list-style-type: none"> Bachelor degree in environmental science/engineering from a recognised institution or equivalent tertiary study in technical area Minimum 10 years experience in environmental practice Familiarisation with relevant requirements of the OSMP and OPEP Monitoring Provider – Socioeconomic and Heritage Specialist <ul style="list-style-type: none"> Bachelor degree in environmental or social science from a recognised institution or equivalent tertiary study in technical area Minimum 10 years experience in environmental/social practice Experienced in interpretation and management of heritage, social and economic data Monitoring Provider – Field Personnel <ul style="list-style-type: none"> Bachelor degree in environmental science/engineering from a recognised institution or equivalent tertiary study in technical area Minimum 5 years experience in environmental practice Experienced in the relevant sampling and/or recording techniques Monitoring Provider – Office Personnel <ul style="list-style-type: none"> Bachelor degree in environmental science/engineering from a recognised institution or equivalent tertiary study in technical area Minimum 5 years experience in environmental practice Experience in analysis and interpretation of heritage, social and economic data Vessel provider <ul style="list-style-type: none"> Certificate of survey with appropriate service category

6 References/Associated documents

1. AMSA. 2019. National Plan for Maritime Environmental Emergencies. Australian Maritime Safety Authority, Australian Government.
2. ANZG. 2018. Australian and New Zealand Guidelines for Fresh and Marine Water Quality. Australian and New Zealand Governments.
3. APPEA. 2019. (Draft) Joint Industry Operational and Scientific Monitoring Plan Framework. Australian Petroleum Production & Exploration Association.
4. API. 2013. Industry Recommended Subsea Dispersant Monitoring Plan. API Technical Report 1152. American Petroleum Institute, Washington, United States of America.
5. Beyers, D.W. 1998. Casual inference in environmental impact studies. *Journal of the North American Benthological Society*. 17: 367–373.
6. Downes, B.J., Barmuta, L.A., Fairweather, P.G., Faith, D.P., Keough, M.J., Lake, P.S., Mapstone, B.D., Quinn, G.P. 2002. *Monitoring ecological impacts, concepts and practice in flowing waters*. Cambridge University Press. Cambridge UK.
7. Edmunds, M. and Hart, P. 2005. Parks Victoria Standard Operating Procedure, Biological Monitoring of Subtidal Reefs. Parks Victoria Technical Series No. 9, Parks Victoria, Melbourne, Australia.
8. Fabricius, K.E., De'ath, G. 2004. Identifying ecological change and its causes: a case study on coral reefs. *Ecological Applications*. 14: 1448–1465.
9. Gotelli, N.J. and Ellison, A.M. 2004. *A primer of Ecological Statistics*. Sinauer Associates. Massachusetts, USA.
10. Hart, P. and Edmunds, M. 2005. Parks Victoria Standard Operating Procedure, Biological Monitoring of Intertidal Reefs. Parks Victoria Technical Series No. 21, Parks Victoria, Melbourne, Australia.
11. Hill, A.B. 1965. The environment and disease: association or causation? *Proceedings of the Royal Society of Medicine*. 58: 295–300.
12. Hook, S., Batley, G., Holloway, M., Irving, P. and Ross, A. (eds). 2016. *Oil spill monitoring handbook*. Commonwealth Scientific and Industrial Research Organisation (CSIRO) Publishing, Australia.
13. McArdle, B.H. 1996. Levels of evidence in studies of competition, predation and disease. *New Zealand Journal of Ecology*. 20: 7–15.
14. NOAA. 2006, *Special Monitoring of Applied Response Technologies*. National Oceanic and Atmospheric Administration, United States Department of Commerce. Accessed on 23 March 2018, https://response.restoration.noaa.gov/sites/default/files/SMART_protocol.pdf
15. NOPSEMA. 2016. Information Paper - Operational and scientific monitoring programs. Doc: N-04700-IP1349. National Offshore Petroleum Safety and Environmental Management Authority, Australian Government.
16. NOPSEMA. 2018. Guidance Note - Oil pollution risk management. Doc: GN1488. National Offshore Petroleum Safety and Environmental Management Authority, Australian Government.

17. NOPSEMA. 2019. Bulletin #1 – Oil Spill Modelling. Doc: A652993. National Offshore Petroleum Safety and Environmental Management Authority, Australian Government.
18. OSRL. 2015. Dispersant Application Monitoring Field Guide, Tier I Visual Observation. Oil Spill Response Limited, United Kingdom.
19. Safe Work Australia. 2018. Workplace Exposure Standards for Airborne Contaminants. Safe Work Australia, Canberra.
20. Simpson, S., Batley, G. and Chariton, A. 2013. Revision of the ANZECC/ARMCANZ Sediment Quality Guidelines. CSIRO Land and Water Science Report 08/07. CSIRO Land and Water.
21. Suter, G.W., 1996. Abuse of hypothesis testing statistics in ecological risk assessment. Human and Ecological Risk Assessment: An International Journal 2: 331-347.
22. Underwood, A.J. 1991. Beyond BACI: experimental designs for detecting human environmental impacts on temporal variations in natural populations. Australian Journal of Marine and Freshwater Research 42: 569–587.
23. Underwood, A.J. 1994. On beyond BACI: sampling designs that might reliably detect environmental disturbances. Ecological Applications 4: 3–15.
24. US EPA. 2015. Acute and Chronic Screening Benchmarks for Water and Sediment Quality - EPA Response to BP Spill in the Gulf of Mexico. US Environmental Protection Agency. Available from: <https://archive.epa.gov/emergency/bpspill/web/html/index.html>. Accessed: June 2018.
25. US EPA. 2017. National Recommended Water Quality Criteria - Aquatic Life. US Environmental Protection Agency. Available from: <https://www.epa.gov/wqc/national-recommended-water-quality-criteria-aquatic-life-criteria-table>. Accessed: June 2018.
26. Yender, R., J. Michel, and C. Lord. 2002. Managing Seafood Safety after an Oil Spill. Seattle: Hazardous Materials Response Division, Office of Response and Restoration, National Oceanic and Atmospheric Administration.

7 Document information and history

Revision History

Rev	Date	Changes made in document	Reviewer/s	Consolidator	Approver
0	19/06/2019	N/A	PW	GLE	TF
1	04/11/2019	Changes in response NOPSEMA RFFWI 5 September 2019	PW	Xodus	PW
2	19/12/2019	Changes in response NOPSEMA OMR 4 December 2019	PW	Xodus	PW
3	28/01/2020	Changes in response to NOPSEMA RFFWI 14 January 2020	PW	Xodus	PW
4	26/02/2020	Changes in response to NOPSEMA RFFWI 21 February 2020	PW	Xodus	PW

Appendix A Approaches for Scientific Monitoring Design

This appendix provides guidance (as provided in APPEA 2019) on survey design approaches that may be utilised for scientific monitoring:

- Impact versus Control (IvC)
- Gradient of Impacts
- Before-After-Control-Impact (BACI)
- Control Chart
- Lines of Evidence.

The design of monitoring studies should ensure, as far as possible, that the planned monitoring activities are practicable and that the objectives of the study will be met. The design must result in the collection of meaningful data and, where practicable, data that are sufficiently powerful to detect ecologically relevant changes.

The final survey design(s) can depend on a variety of factors, included but not limited to:

- Scale and pattern of potential effects of the spill
- Availability of baseline data and/or ability to rapidly obtain baseline data
- Time frame available to gather pre- and post-spill data
- Availability of operational monitoring data
- Availability of appropriate control sites
- Statistical approach proposed for data analysis
- Range of possible chronic and acute effects on the parameters of concern, based on the characteristics of the spill
- Monitoring frequency required to ensure short-and long-term impacts are detected
- Legislative requirements
- Available resources and equipment to conduct the work in terms of personnel, logistics, and access.

Note: data collection can depend on several constraints (as outlined above) and on access given logistical and safety constraints applicable to a spill event. Therefore, the survey designs recommended within the implementation guides for each scientific monitoring module, may not be able to be implemented exactly as intended. For example, there may be inadequate number of control sites because of the size of the spill and therefore data collected from an expected BACI design may need to be analysed as a gradient approach etc.


A. 1. Before-After-Control-Impact (BACI) approach

Where appropriate baseline data are available, consideration should be given to developing a beyond BACI monitoring program design (Underwood 1991; 1994) or similar extended BACI design (MBACI), which monitors a range of control and impact sites, and can do so over time (Figure A-1). Where robust, appropriate baseline data for exposure sites are not

available, pre-exposure sampling of locations that lie within the hydrocarbon spill trajectory should be prioritised to obtain baseline data prior to hydrocarbon exposure.

Exposure sites should be selected first, encompassing a representative selection of locations within the area affected by hydrocarbons. Where practicable, the monitoring program design may consider stratified sampling along environmental gradients (e.g. level of hydrocarbon exposure etc.). Comparable control sites beyond the area affected by hydrocarbons should then be selected, with monitoring conducted at all sites. Clearly obtaining control sites pre-exposure can be challenging and is heavily reliant on predicting the extent of hydrocarbon movement.

The suggested statistical analysis of data collected using the BACI approach includes a univariate or multi-factorial analysis of variance (ANOVA) and equivalent non-parametric tests, all of which will compare between treatment (impact versus reference) and time (before versus after). Components of variation may help partition a sum of squares into different sources and describe the importance of factors within tests.



(Source: APPEA 2019)

Notes:

1. A modification to the beyond BACI design, is known as an MBACI design. MBACI designs incorporate multiple impact locations, whereas beyond BACI designs include only one impact location.
2. The above design consists of four reference/control locations and two impact locations, with four nested sites in each. The number of replicates (e.g. quadrats or transects) per site should be set based on resourcing, and /or the results of the power analysis (if applicable).
3. The area affected by the spill is indicated by the grey shaded area, or the area of influence.
4. Design assumes the area of influence has been affected equally.

Figure A-1: Example of an MBACI design for shoreline and/or intertidal communities

A. 2. Impact versus Control (IvC) approach

For some locations and receptors, baseline data may not exist, may not be recent and applicable, or was collected using methods that are unrepeatably in the current study. If there is a lack of baseline information that can feed into a BACI design, an IvC approach can be used to assess impacts. However, due to the unknown status of the parameter before impact, there is a higher likelihood of encountering Type I error (falsely concluding that an impact has occurred) with this approach. For example, if the status of the parameter to be measured was already naturally lower at impact sites than control sites before the impact occurred, but this was not measured, a conclusion may be reached using the IvC approach that an impact has occurred when it may be natural variation. For this reason, sampling designs should always try to collect or use baseline data (i.e. aim for a BACI design), and if an IvC design is used, it is important to ensure that the control sites are comparable to the impact sites in every way possible except for the presence or absence of the studied effect (hydrocarbon). This may include, but not be limited to, site physical aspect, substrate, current regimes, and community composition.

Because of the higher likelihood of Type I error, it is also useful to collect additional data on relevant physical environmental parameters that are likely to be different at impact and control sites and may affect the conclusion of the assessment. Biological information may also be relevant, such as degree of sub-lethal and lethal impacts to populations. These parameters can be examined later for any potential co-variance with the observed changes in the parameter of interest, to understand whether hydrocarbons or natural variation affected the outcome. The physical and biological information can therefore augment and act as additional evidence to help interpret conclusions from any IvC analyses. As with the BACI approach, when using the IvC approach it is important to understand the scale of natural variation that may affect the outcome of the assessment by replicating sites within sampling locations and replicating samples within each site.

The suggested statistical approach for analysing the data collected using the IvC approach is a multi-factorial ANOVA (to account for nested data), including PERMANOVA and non-parametric tests, to test whether the level of variation among treatments (IvC) is greater than the level of variation within treatments. Components of variation may help partition variance into different sources and help infer whether the effect of hydrocarbons or spatial variation was responsible for any detected change in the receptors.

A. 3. Gradient approach

The gradient approach can be used in some instances where a lack of suitable control sites prohibits using a BACI or IvC approach. Sampling should be established along a gradient of predicted effect (based on input of data from operational monitoring, surveillance or modelling), with sites established at various distances from the source of impact or along a gradient of magnitudes of concentrations of hydrocarbons. The gradient approach can also be used in combination with a BACI or IvC approach to help infer the cause of a detected impact and describe thresholds of impacts at which a response appears to have occurred. The gradient approach also provides a 'line of evidence' that the source of potential impact (hydrocarbons) was responsible for the observed effect, rather than natural variation. However, care should be taken to ensure awareness of any natural gradients in the parameter measured and take these into account when interpreting the data.

When designing a study using a gradient approach, relevant operational and scientific monitoring data (e.g. water and sediment quality), and modelling should be considered. Prior knowledge or prediction of the likely gradient of effect will greatly improve the efficiency of the sampling design by minimising the collection of data points that provide no additional information in the analysis (e.g. data points showing similar or no effects that do not help to characterise the gradient of effect), though noting these may aid in statistical power of gradient description so shouldn't necessarily be discouraged.

Typically, the level of observed impact will decline at distance from the source of a hydrocarbon release, with this decline likely to be exponential (i.e. large changes close to a release that quickly decrease in severity); therefore, sampling effort can be distributed along the gradient of effect in a way that best characterises the changes in the parameter measured.

If possible, multiple (> two) sites could be sampled at each distance along the gradient (if logistics and time permit) to provide an understanding of small-scale variation. Sites should also be sampled at distances where no environmental effect is predicted or observed, if possible, to characterise the full extent of the effect's gradient.

The suggested statistical analysis for the gradient approach includes correlation analysis between impact (measurements of hydrocarbon/stress; x-axis) and measurement parameter (biological response; y-axis), and associated regression analyses, may include least-squares regression line and hypotheses testing to determine if the trend is significantly different from zero.

A. 4. Control chart approach

The control chart approach is applicable in the following circumstances:


- When long-term (multi-year) datasets exist for the measured parameter;
- When a large amount of natural variation exists in the measured parameter;
- When predicting the expected range of outcomes from an impact.

One of the causal criteria described in the lines of evidence approach is 'strength of association' (Hill 1965), exemplified by a 'larger decline in individuals in areas affected by hydrocarbon than in control areas'. The control chart approach takes this causal criterion a step further and uses rules to establish whether a detected change in a parameter at impact sites is outside what would be expected to occur naturally. This technique requires tracking a parameter over time and determining whether an observed change is within the bounds of what has been observed to occur naturally at that impact site or at control sites.

A control chart has a central line for the mean, an upper control limit (UCL; e.g. typically 3 standard deviations [SD] above the mean), and a lower control limit (LCL; e.g. typically 3SD below the mean), which are typically all determined from historical data (Gotelli and Ellison 2004). The mean line can be constructed using data from i) historical data of an impact site prior to it being affected by hydrocarbons (i.e. what the mean used to be), or ii) control locations, whereby either historical or recent data is used for comparison to other sites (i.e. a control site historical data compared to impact site). The approach is then based on calculating the mean (ongoing) for an impact site to compare against the control chart. Any observations outside the UCL and LCL suggest that increased variation has been observed that are inconsistent with other data and may post a simple way to detect change in a system (Figure A-2).

In addition, if ongoing data collection is possible following a potential impact, the control chart approach can be used to examine the direction of change and whether this is consistent or inconsistent with other data. These data and interpretation may provide a weight of evidence of a directional change in a given parameter.

The control chart approach is only useful if there is an adequate knowledge of natural variability in a given parameter whether from historical sources or similar sites/locations. Control chart approaches can be a powerful tool for detecting impacts for systems that are naturally highly variable.



(Source: APPEA 2019)

Note: The star represents a measurement beyond the likely anticipated variation, which needs to be investigated.

Figure A-2: Example Control Chart showing Centreline (mean), Upper Control Limit (3 SD above mean), Lower Control Limit (3 SD below mean), and Measurements

A. 5. Lines of evidence approach

The lines of evidence approach is applicable in the following circumstances:

- Can be combined with any of the above monitoring designs to provide inferential evidence of an effect;
- Are useful to support evidence of effect if there are limited (or only one) impact locations;
- Are useful to support evidence of effect if the effect radiates outward from source;
- Are useful to infer cause of change if limited or no baseline data exist;
- Are useful to infer cause of change if limited or no control sites exist.

When a sampling design is suboptimal, or if conclusions from more formal tests are inconclusive, a lines of evidence approach can be used to help infer the cause of an observed change (i.e. attribute change to the hydrocarbon release or to other causes, such as natural variation). Within the lines of evidence approach, inference is developed based on carefully structured arguments. A weakness of this method is that the evidence may be largely circumstantial because it is based on correlations (Downes et al. 2002), which does not necessarily imply causation. Each causal argument may be weak when considered independently but combined they may provide strong circumstantial evidence and support for a conclusion (Downes et al. 2002).

This approach was originally developed in medicine (Hill 1965) but has been used more recently in ecological studies (e.g. Downes et al. 2002; McArdle 1996; Suter 1996; Beyers 1998; Fabricius 2004). Causal criteria have been developed for categorizing arguments from studies on disease on humans (Hill 1965), and these can be applied to ecological arguments (Hill 1965). With lines of evidence, there is a need to seek evidence not only to support the impact prediction, but evidence to rule out plausible alternative predictions, such as that the observed difference was due to natural processes (Downes et al. 2002; Beyers 1998).

In the lines of evidence approach, a set of descriptions should be developed for all or some of the causal criteria listed in Table A-1 before the survey is undertaken (see Downes et al. 2002 for further criteria and examples). Data would then be collected that allows each line of evidence to be tested or objectively questioned. The final assessment of whether an impact is likely to have occurred should be based on the 'weight of evidence' from examining multiple lines of evidence.

Example generalised lines of evidence descriptions are provided in Table A-2. These should be modified and tailored to individual scientific monitoring module, as required and each parameter investigated.

Table A-1: Causal criteria and description in the context of ecological impact Assessment

(Source: Hills 1965, in APPEA 2019)

Causal criterion	Description
Strength of association	A large proportion of individuals are affected in the impact area relative to control areas
Consistency of association	The association was observed by other investigators at other times and places
Specificity of association	The effect is diagnostic of exposure
Temporality	Exposure must precede the effect in time
Biological gradient	The risk of effect is a function of magnitude of exposure
Biological plausibility	A plausible mechanism of action links cause and effect
Experimental evidence	A valid experiment provides strong evidence of causation
Coherence	Similar stressors cause similar effects
Analogy	The causal hypothesis does not conflict with existing knowledge of natural history and biology

Table A-2: Causal criteria and example lines of evidence descriptions that could be used to assess whether a change in a measured parameter was due to the effects of a hydrocarbon release

(Source: APPEA 2019)

Causal criterion	Evidence supportive of a hydrocarbon release impact	Evidence unsupportive of a hydrocarbon release impact
Strength of association	Larger decline in individuals in areas affected by hydrocarbon than in control areas	Similar declines in individuals in areas affected by hydrocarbon and control areas
Consistency of association	Consistent finding of declines in a range of biota in areas affected by hydrocarbon	Inconsistent declines in biota in areas affected by hydrocarbon (e.g. declines in one species but not in other similar species)
Specificity of association	Number of individuals affected correlates with hydrocarbon concentrations	No correlation between number of individuals affected and hydrocarbon concentration
Temporality	Decline in individuals immediately preceded by contact with hydrocarbon	Decline in individuals occurred before or long after hydrocarbon contact

Causal criterion	Evidence supportive of a hydrocarbon release impact	Evidence unsupportive of a hydrocarbon release impact
Biological gradient	Changes in individuals aligned with exposure to hydrocarbon spills or concentrations	Decline in individuals occurs with increasing distance from a hydrocarbon spill or hydrocarbon concentrations
Biological plausibility	Evidence from literature of sensitivity to detected hydrocarbon concentration for species where declines are observed	Evidence from literature suggests lack of sensitivity to detected hydrocarbon concentration for species where declines are observed
Experimental evidence	A valid experiment provides strong evidence of causation	Not applicable (N/A)
Coherence	Evidence of a decline in species abundance, habitat, and food source with increasing hydrocarbon exposure	Evidence of a decline in species abundance, but no other evidence of expected declines associated with exposure
Analogy	Apparent declines in hatchling numbers despite no apparent decline in numbers of adults	Apparent declines in hatchling numbers associated with decreased numbers of adults

Appendix B Baseline Information

A database of known literature and studies relevant to environmental receptors within the Otway and Bass Basins that may provide suitable baseline data and/or contextual information in the event of a spill.

Source	Description	Relevant Scientific Monitoring Study
Group / Agency		
Birdlife Australia	Shorebirds 2020	S5: Marine fauna impact assessment
Parks Victoria	Signs of Healthy Parks program, including: <ul style="list-style-type: none"> • Subtidal Reef Monitoring Program <ul style="list-style-type: none"> ◦ Popes Eye Component of the Port Phillip Heads MNP ◦ Reef Biota at Beware Reef Marine Sanctuary ◦ Reef Biota at Bunurong Marine National Park and Surrounding Coast ◦ Reef Biota at Eagle Rock Marine Sanctuary ◦ Reef Biota at Jawbone Marine Sanctuary ◦ Reef Biota at Marengo Reefs Marine Sanctuary ◦ Reef Biota at Marine Protected Areas in the Twofold Shelf region ◦ Reef Biota at Merri Marine Sanctuary ◦ Reef Biota at Phillip Island ◦ Reef Biota at Point Addis Marine National Park ◦ Reef Biota at Port Phillip Bay Marine Sanctuaries ◦ Reef Biota at Port Phillip Heads Marine National Park ◦ Reef Biota at Ricketts Point Marine Sanctuary ◦ Reef Biota at Wilsons Promontory Marine National Park ◦ Reef Biota on the Western Victorian Coast ◦ Reef Biota within the Twofold Shelf Bioregion ◦ Reef Surveys at Twelve Apostles Marine National Park and The Arches Marine Sanctuary ◦ The Reef Biota at Point Cooke Marine Sanctuary ◦ Western Victorian Coast • Intertidal Reef Monitoring Program <ul style="list-style-type: none"> ◦ Intertidal Reef Biota of Central Victoria's Marine Protected Areas ◦ Intertidal Reef Biota of Northern Port Phillip Bay Marine Sanctuaries ◦ Reef biota in Central Victoria and Port Phillip Bay Marine Sanctuaries • Shallow Water Habitat Mapping at Victorian Marine National Parks and Marine Sanctuaries <ul style="list-style-type: none"> ◦ Eastern Victoria ◦ Western Victoria 	S3: Subtidal habitats impact assessment S4: Intertidal and coastal habitats impact assessment S3: Subtidal habitats impact assessment S4: Intertidal and coastal habitats impact assessment

Source	Description	Relevant Scientific Monitoring Study
	<ul style="list-style-type: none"> Mapping the Benthos in Victoria's Marine National Parks <ul style="list-style-type: none"> Cape Howe Marine National Park Discovery Bay Marine National Park Point Addis Marine National Park Point Hicks Marine National Park Twelve Apostles Marine National Park 	S3: Subtidal habitats impact assessment S4: Intertidal and coastal habitats impact assessment
	<ul style="list-style-type: none"> Reef Life Survey 	S3: Subtidal habitats impact assessment
	<ul style="list-style-type: none"> Community-based monitoring programs, including: <ul style="list-style-type: none"> Intertidal Rocky Shore Monitoring Seagrass Monitoring Subtidal Reef Monitoring 	S3: Subtidal habitats impact assessment S4: Intertidal and coastal habitats impact assessment
	<ul style="list-style-type: none"> Marine Natural Values Study, including: <ul style="list-style-type: none"> Marine Protected Areas of the Otway Bioregion Marine Protected Areas of the Central Victoria Bioregion Marine Protected Areas of the Victorian Embayments Bioregion Marine Protected Areas of the Victorian Embayments Bioregion Marine Protected Areas of the Flinders and Twofold Shelf Bioregions 	S1: Water quality S2: Sediment quality S3: Subtidal habitats impact assessment S4: Intertidal and coastal habitats impact assessment S5: Marine fauna impact assessment
	Other publications, including:	
	<ul style="list-style-type: none"> Marine Habitat Mapping Project 	S3: Subtidal habitats impact assessment
	<ul style="list-style-type: none"> Species diversity and composition of benthic infaunal communities found in Marine National Parks along the outer Victorian coast 	S4: Intertidal and coastal habitats impact assessment
	<ul style="list-style-type: none"> Managing Hooded Plover in Victoria 	S5: Marine fauna impact assessment
	<ul style="list-style-type: none"> Birds as Environmental Indicators 	S5: Marine fauna impact assessment
	<ul style="list-style-type: none"> Rocky Shores of Marine National Parks and Sanctuaries on the Surf Coast Shire – Values, uses and impacts 	S4: Intertidal and coastal habitats impact assessment
	<ul style="list-style-type: none"> Identification of threats to natural values in Victoria's Marine National Parks and Marine Sanctuaries 	S3: Subtidal habitats impact assessment S4: Intertidal and coastal habitats impact assessment S5: Marine fauna impact assessment
	<ul style="list-style-type: none"> Monitoring the macroinvertebrates and soft sediments in the Marine National Parks in Western Port 	S4: Intertidal and coastal habitats impact assessment
	<ul style="list-style-type: none"> Mud Islands Seagrass and Coastline Mapping 2011-12 	S4: Intertidal and coastal habitats impact assessment
	<ul style="list-style-type: none"> Yaringa and French Island MNP Habitat Mapping 	S3: Subtidal habitats impact assessment S4: Intertidal and coastal habitats impact assessment

Source	Description	Relevant Scientific Monitoring Study
Victorian National Parks Association	Reefwatch	S3: Subtidal habitats impact assessment
Journals		
Deep-Sea Research Part II: Topical Studies in Oceanography	McCauley, R. D., A. N. Gavrilov, C. D. Jolliffe, R. Ward, and P. C. Gill. (2018). Pygmy blue and Antarctic blue whale presence, distribution and population parameters in southern Australia based on passive acoustics. <i>Deep-Sea Research Part II: Topical Studies in Oceanography</i> 157-158: 154-168	S5: Marine fauna impact assessment
Marine Ecology Progress Series	Bruce, B. D., D. Harasti, K. Lee, C. Gallen & R. Bradford. (2019). Broad-scale movements of juvenile white sharks <i>Carcharodon carcharias</i> in eastern Australia from acoustic and satellite telemetry. <i>Marine Ecology Progress Series</i> , 619: 1-15	S5: Marine fauna impact assessment
	Gill, P.C., M.G. Morrice, B. Page, R. Pirzl, A.H. Levings and M. Coyne (2011). Blue whale habitat selection and within-season distribution in a regional upwelling system off southern Australia. <i>Marine Ecology Progress Series</i> , 421: 243–263.	S5: Marine fauna impact assessment
Marine Mammal Science	Kirkwood, R., Warneke, R.M., Arnould, J.P. (2009). Recolonization of Bass Strait, Australia, by the New Zealand fur seal, <i>Arctocephalus forsteri</i> . <i>Marine Mammal Science</i> 25(2): 441–449	S5: Marine fauna impact assessment
The Journal of Wildlife Management	Gill, P.C., R. Pirzl, M.G. Morrice & K. Lawton (2015). Cetacean diversity of the continental shelf and slope off southern Australia. <i>The Journal of Wildlife Management</i> .	S5: Marine fauna impact assessment
Universities		
Curtin University Centre for Marine Science	Gavrilov, A. (2012). Seismic signal transmission, pygmy blue whale abundance and passage and ambient noise measurements during and after the Bellerive seismic survey in Bass Strait, 2011, Curtin University centre for Marine Science	S5: Marine fauna impact assessment